


Owner's Manual & Assembly Instructions

ACV01et

Model No. VM1010



Missing Parts, Questions on Assembly?

Call: 1-800-851-1085 or

assist@arrowsheds.com

**Do not return to dealer, they are not
equipped to handle your requests.**

718590713

Storage Area: 92 Sq. Ft. 580 Cu. Ft.
8,5 m² 16,4 m³



**CAUTION: SOME PARTS HAVE SHARP EDGES. CARE
MUST BE TAKEN WHEN HANDLING THE VARIOUS PIECES
TO AVOID A MISHAP. FOR SAFETY SAKE, PLEASE READ
SAFETY INFORMATION PROVIDED IN THIS MANUAL
BEFORE BEGINNING CONSTRUCTION. WEAR GLOVES
WHEN HANDLING METAL PARTS.**

BUILDING DIMENSIONS * Size rounded off to the nearest foot

*Approx. Size	Base Size	Exterior Dimensions (Roof Edge to Roof Edge)			Interior Dimensions (Wall to Wall)			Door Opening	
		Width	Depth	Height	Width	Depth	Height	Width	Height
10' x 10'	121" x 114 1/2"	123 1/4"	117"	86"	118 1/4"	111 3/4"	84 3/4"	55 1/2"	64 1/2"
3,0 m x 2,8 m	307,3 cm x 290,8 cm	313,1 cm	297,2 cm	218,4 cm	300,4 cm	283,8 cm	215,3 cm	141,0 cm	163,8 cm

BEFORE YOU BEGIN....

Owner's Manual

Before beginning construction, check local building codes regarding footings, location and other requirements. Study and understand this owner's manual.

Important information and helpful tips will make your construction easier and more enjoyable.

Assembly Instructions: Instructions are supplied in this manual and contain all appropriate information for your building model. Review all instructions before you begin, and during assembly, follow the step sequence carefully for successful results.

Flooring and Anchoring: Your storage building must be anchored to prevent wind damage. A base is necessary to construct a square and level building. Anchoring and base materials are not included with your building. We recommend the combined use of an **Arrow Floor Frame Kit** and an **Arrow Anchoring Kit** as an effective method of securing your building to the ground (Available at your local dealer, Arrow's website arrowsheds.com or call Arrow's Customer Service department 1-800-851-1085) or you may construct a base and anchoring system of your choice. Your assembly instructions provide information on a few methods commonly used to secure and level a storage building.

Parts and Parts List: Check to be sure that you have all the necessary parts for your building.

- All part numbers can be found on the parts. All of these numbers (before the -) must agree with the numbers on the Parts List page.

- If you find that a part is missing, include the model number of your building and contact:

Arrow Shed, LLC Customer Service Department
1101 North 4th Street Breese, Illinois 62230

1-800-851-1085 or assist@arrowsheds.com

- Separate contents of the carton by the part number while reviewing parts list. The first few steps show how to join related parts to make larger sub assemblies which will be used later.


- Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

PLAN AHEAD....

Watch the Weather: Be sure the day you select to install your building is dry and calm. Do not attempt to assemble your building on a windy day. Be careful on wet or muddy ground.

Teamwork: Whenever possible, two or more people should work together to assemble your building. One person can position parts or panels while the other is able to handle the fasteners and the tools.

Tools and Materials: These are some basic tools and materials you will need for the construction of your building. Decide which method of anchoring and the type of base you wish to use in order to form a complete list of the materials you will need.



Selecting and Preparing Your Site: Before assembly, you will want to decide on a location for your building. The best location is a level area with good drainage.


- Allow enough working space for ease of moving parts into position during assembly. Be sure there will be enough space at entrance for doors to open fully and enough space around the building to be able to fasten the panel screws from the outside.

- Before you begin the first steps in assembling your parts, a base should be constructed and an anchoring system should be ready to use.

SAFETY FIRST....

Safety precautions are important to follow throughout the construction of your building.


•Care must be taken when handling various pieces of your building since some contain sharp edges. Please wear work gloves, eye protection and long sleeves when assembling or performing any maintenance on your building.




•Keep children and pets away from worksite to avoid distractions and any accidents which may occur.




•Never concentrate your total weight on the roof of the building. When using a step ladder make sure that it is fully open and on even ground before climbing on it.




•Practice caution with the tools being used in the assembly of this building. Be familiar with the operation of all power tools.



•Do not attempt to assemble the building if parts are missing because any building left partially assembled may be seriously damaged by light winds. Call 1-800-851-1085 or assist@arrowsheds.com



•Do not attempt to assemble the building on a windy day, because the large panels acting as a "sail", can be whipped about by the wind making construction difficult and unsafe.



CARE & MAINTENANCE....

Finish: For long lasting finish, periodically clean and wax the exterior surface. Touch-up scratches as soon as you notice them on your unit. Immediately clean the area with a wire brush; wash it and apply touch-up paint per manufacturer's recommendation.

Roof: Keep roof clear of leaves and snow with long handled, soft-bristled broom. Heavy amounts of snow on roof can damage building making it unsafe to enter. In snow country, Roof Strengthening Kits are available for most Arrow Buildings for added protection against heavy snow accumulation. Contact **Arrow** as outlined on the Ordering Accessories page to place an order.

Doors: Always keep the door tracks clear of dirt and other debris that prevent them from sliding easily. Lubricate door track annually with furniture polish or silicone spray. Keep doors closed and locked to prevent wind damage.

Fasteners: Use all washers supplied to protect against weather infiltration and to protect the metal from being scratched by screws. Regularly check your building for loose screws, bolts, nuts, etc. and retighten them as necessary.

Moisture: A plastic sheet (vapor barrier) placed under the entire floor area with good ventilation will reduce condensation.

Other Tips....

- Wash off inked part numbers on coated panels with soap and water.
- Silicone caulking may be used for watertight seals throughout the building.


Do not store swimming pool chemicals in your building. Combustibles and corrosives must be stored in air tight approved containers.

Keep this Owner's Manual and Assembly Instructions for future reference.

ACCESSORIES....

ROOF STRENGTHENING (heavy snow load) KITS


Extra roof beams and gable braces designed for added protection against heavy snow accumulation. Increases the strength of your roof by 50%.



ANCHOR KITS


Model No. AK4

Anchor Kit contains heavy-duty steel augers, 60' (18 m) of steel cable and 4 cable clamps. No digging or concrete pouring, just insert cable under roof, over roof beams, into augers and twist augers into the ground. For buildings larger than 10'x9' (3,0 m x 2,6 m), use 2 kits.




Model No. AK100

New concrete anchor system permits anchoring any size Arrow building directly to a concrete slab. Each kit contains heavy-duty, hot-dipped galvanized steel corner gussets and perimeter clips which fit over the floor frame and lag bolt into a concrete slab. Full assembly instructions and a 1/4" masonry drill bit are included.



Model No. AK600


Earth Anchor Kit anchors any size Arrow building to the ground. Each kit contains heavy duty, hot-dipped galvanized steel corner gussets and 4 earth anchors.




TOOL HANGING RACK

Model No. TH100

The perfect tool organizer. Twin 25 1/2" (64,8 cm) steel channels plus five heavy-duty snap-in hangers and a small tool holder for screwdrivers, pliers, etc. Holders slide along channel for fully adjustable spacing. Great for garage, basement, or the back of any door. Fits all Arrow storage buildings.



FLOOR FRAME KITS




MODELS FB47410, FB5465, FB106-A
FB109-A and FB1014-A

A simple new floor frame system made of heavy-duty, hot-dipped galvanized steel. Use as base for plywood, sand or stone.

ATTIC KIT / WORKBENCH KIT

Model No. AT101




Heavy-duty galvanized steel bars that fit all 10' (3,0 m) wide Arrow buildings. They install quickly and easily to help organize space and create more useable space as an attic or workbench. Will hold up to 250 lbs. (113 kg) evenly distributed.



Some drilling required to fit buildings without mid-wall bracing.

SHELF UNITS

Heavy-duty, galvanized steel shelf units help organize storage space. They easily mount on the wall or sit on the floor. Fits all Arrow buildings.*



Model No. SS404

- Makes 8" to 12" (20,3-30,5 cm) wide shelves in any length.
- Brackets, braces, hardware included. Lumber is not included.

Model No. SS900-B

- Grey color
- 3 shelves
- Holds up to 85 lbs. (38 kg) (even weight distribution)

* Some drilling required to fit buildings without mid-wall bracing.

ORDERING ACCESSORIES....

A08

02/13

We recommend that you purchase accessory items from your local storage building dealer whenever possible; however, because the full line of accessories is not always available from all dealers, **Arrow** is offering them to you on a direct basis.

There are two ways to order Arrow Storage Building Accessories:

Option 1

Accessories can be purchased
through

arrowsheds.com

Option 2

Order accessories by telephone
using your MasterCard or Visa credit card.

Call toll free **1-800-851-1085**
(Customer Service).

Allow 2 weeks for delivery.


SPECIAL NOTE:

If your accessory is shipped via truck line a day time phone number is required to arrange delivery. If no one is available to sign for the delivery, you may be subject to a re-delivery charge assessed by the carrier.

Base

The Base For Your Building

No matter which of the options below you choose for a base, an ARROW ANCHORING KIT is recommended as an effective method of properly securing your building after assembly is complete.



OPTION 1: Directly on ground (earth)

Assemble your building directly on level ground (grass, dirt, rock, sand, etc.). If you choose this option Arrow has a simple kit available to provide a floor inside the shed to keep stored items off the ground. This kit can be used to support a plywood floor (wood not included) or be filled with sand/rock to provide a solid surface. (Order No. FB109-A or 68385-A)

Allow 1 - 2 hours for construction.

OPTION 2: Wood Platform

If you decide to build your own base, be sure to select the appropriate materials.

These are the recommended materials for your base:

- 2 x 4's (38 mm x 89 mm) Pressure Treated Lumber
- 5/8" (15,5 mm) 4 x 8 (1220 mm x 2440 mm) Plywood-exterior grade
- NOTE: Pressure Treated Lumber must not be used where it will make contact with your storage building. The properties of Pressure Treated Lumber will cause accelerated corrosion.
- If Pressure Treated Lumber comes in contact with your storage building your warranty will be voided.
- 10 & 4 penny Galvanized Nails ● Concrete Blocks (optional)


The platform should be level and flat (free of bumps, ridges etc.) to provide good support for the building. The necessary materials may be obtained from your local lumber yard.

To construct the base follow instructions and diagram.

Construct frame (using 10 penny galvanized nails)

Measure 16"/24" (40,6 cm/61,0 cm) sections to construct inside frame (see diagram)

Secure plywood to frame (using 4 penny galvanized nails)



Allow 6 - 7 hours for construction.

Note: Platform/Slab will extend 9/16" (1,4 cm) beyond floor frame on all four sides. Seal this 9/16" (1,4 cm) of wood with a roofing cement (not included), or bevel this 9/16" (1,4 cm) of concrete when pouring, for good water drainage.

OPTION 3: Concrete Slab


The slab should be at least 4" (10,2 cm) thick. It must be level and flat to provide good support for the frame.

The following are the recommended materials for your base.

- 1 x 4's (19 mm x 89 mm) (will be removed once the concrete cures)
- Concrete ● Sheet of 6 mil plastic
- We recommend for a proper strength concrete to use a mix of:
1 part cement ● 3 parts pea sized gravel ● 2 1/2 parts clean sand

Prepare the Site/Construct a Base

1. Dig a square, 6" (15,2 cm) deep into the ground (remove grass).
2. Fill up to 4" (10,2 cm) in the square with gravel and tamp firm.
3. Cover gravel with a sheet of 6 mil plastic.
4. Construct a wood frame using four planks of 1x4 (19 mm x 89 mm) lumber.
5. Pour in concrete to fill in the hole and the frame giving a total of 4" (10,2 cm) thick concrete. Be sure surface is level.



Allow 3 - 5 hours for construction and a week for concrete curing time. Note: Finished Slab dimensions, with lumber removed.

Anchoring

A10

Anchoring Down The Building


It is important that the entire floor frame be anchored after the building is erected.

Below are recommended ways of anchoring.

Arrow Anchoring Kit: (Model No. AK4 or 60298)


Recommended for use with **any** suggested base.

Contains: 4 Anchors with Cable, Clamps and installation instruction.



Anchoring into Wood/Post:


Use 1/4" (6 mm) Wood Screws. There are 1/4" (6 mm) dia. holes provided in the frames for proper anchoring.



Arrow Anchoring Kit: (Model No. AK100 or 68383)

Recommended for use with the **concrete** base.


Contains: Corner gussets, perimeter clips, hardware, 1/4" masonry drill bit and installation instruction.



Anchoring into Concrete:

1. For poured concrete slab or footing or patio blocks: Use 1/4" x 2" (6 mm x 51 mm) Lag Screws.

2. For Anchor Post of Concrete poured after building is erected: Use 1/4" x 6" (6 mm x 152 mm) Lag Screws.



Hardware

Remove from bag of screws
and save for the last step



65103
#8-32 Hex Nut (137)



65900A
#10Bx1/2" (13 mm)
Black Screw (8)
(Packed with Screws)




65923
#8-32x3/8" (10 mm)
Bolt (137)




65004
#8Ax5/16" (8 mm)
Screw (328)



66045
Handle (2)




66646
Washer (212)
(6 sheets of 40)




67545
Weather Stripping (1)




67468
Peak Cap (2)




66769
Door Slide (4)



66382
Lower Door Guide (4)



66183
Roof Trim Cap
(2 right & 2 left)




6228
Track Support (2)

Parts List

Assembly Key No.	Part Number	Part Description	Quantity in Carton	Check List
1	3719	Door Handle Brace	2	
2	5290	Front Siding (6 Board)	2	
3	5291	Front Siding (3 Board)	2	
4	5306	Rear Siding (6 Board)	2	
5	5307	Rear Siding (3 Board)	2	
6	5986	Rear Wall Angle	2	
7	10497	Horizontal Door Brace	4	
8	6403	Door Track Splice	1	
9	9366	Door Track	2	
10	6635	Roof Beam Bracket	4	
11	7743	Roof Panel	4	
12	6015	Side Roof Trim	4	
13	6869	Ridge Cap	2	
14	8576	Right Gable	2	
15	8577	Left Gable	2	
16	9086	Right Roof Panel	2	
17	9087	Left Roof Panel	2	
18	10723	Side Siding (6 Board)	4	
19	10724	Side Siding (5 Board)	4	
20	10722	Side Siding (3 Board)	4	
21	8736	Rear Siding (5 Board)	2	
22	8737	Front Siding (5 Board)	2	
23	10518	Roof Beam	8	
24	10521	Side Wall Angle	4	
25	8934	Ramp	1	
26	9367	Front Floor Frame	2	
27	8936	Rear Floor Frame	2	
28	9009	Gable Brace	2	
29	9194	Door Jamb	2	
30	9195	Splice Post	1	
31	9196	Right Corner Post	2	
32	9197	Left Corner Post	2	
33	9198	Side Splice Post	2	
34	9199	Siding Stud	6	
35	10483	Right and Left Doors	2	
36	9202	Vertical Door Brace	2	
37	9299	Side Floor Frame	4	
38	9204	Roof Beam Brace	2	
39	69835	Edge Trim (Green)	4	

Assembly by Key No.




Step 1

S14


● Parts Needed For ● Floor Frame Assemblies

- 8934 Ramp (1)
- 9367 Front Floor Frame (2)
- 8936 Rear Floor Frame (2)
- 9299 Side Floor Frame (4)


The front floor frame is made up of three pieces. The side floor frames and the rear floor frame are made up of two pieces. The holes in these pieces will align when the pieces are positioned with correct amount of overlap. The illustrations below show the proper overall length for the sides, rear and front. Proceed as follows:




1 Place the **front floor frames** as shown. Center the **ramp**, with drain holes facing outside, on top of the two front floor frames. Join the frames by inserting eight screws.



2 Overlap the **side floor frames** and the **rear floor frames** as shown. The holes in these pieces will align when the pieces are positioned with correct amount of overlap. See the illustrations below for the proper overall length of the side and rear floor frames. Join the frames by inserting five bolts into each frame set as shown.



3 Double check the length of each and set these pieces aside for later use.



Step 2

ACV15

● Parts Needed For ● Frame Assemblies



- 5986 Rear Wall Angle (2)
- 10521 Side Wall Angle (4)

The main frame pieces reinforce the walls. These pieces will later be installed at the top edge of the side walls and the rear wall. Proceed as follows:

1 Overlap the rear wall angle pieces as shown in the figure and fasten them together with *one bolt and nut in the center hole*.

2 Make two side wall angles by overlapping the side wall angle pieces as shown. Fasten each set together with *one bolt and nut in the center hole*.

3 Double check the length of each and set these pieces aside for later use.



Step 3

S16

● Parts Needed For ● Roof Beam Assemblies



● 10518 Roof Beam (8)

The roof beams join the two gables and support the roof panels. The main roof beam is made up of four pieces overlapped back to back at the center. The left and right roof beam assemblies are made up of two pieces.

Hint: These pieces are force-fitted, so you may have to press hard to join them together.

STEP
1

1 Place the end of one roof beam inside a second roof beam so that the six holes in each piece align. Make four sets of roof beams by repeating this procedure. **Do not insert bolts yet.**




2 Take two of the pressed-together roof beams and join them as shown to form the main roof beam assembly. Hold the assembly together and fasten with 14 bolts. Build **only one** Doubled Beam Assembly.

STEP
2

3 Fasten the other two pressed-together roof beams with eight bolts to make the left and right roof beam assemblies.

STEP
3

4 Double check the length of each and set these pieces aside for later use.



Step 4

A17

● Parts Needed For ● Door Track Assembly


- 6403 Door Track Splice (1)
- 9366 Door Track (2)

The door track assembly supports the sliding doors and reinforces the front wall. It is made up of three pieces.

1 Using the **door track splice**, (painted), join the **door track** (galvanized) pieces end-to-end as shown.


2 Insert four screws from the *under-side only*.

Hint: The holes in the top side of the door track assembly are for fastening the gable to the top of the front wall in a later step.



3 Position **door slides** onto the legs, from the end of door track assembly, as shown in the end view.

4 Set this piece aside for later use.



Step 5


S18

● Parts Needed For ● Floor Frame

- Front Floor Assembly (1)
- Side Floor Assembly (2)
- Rear Floor Assembly (1)

1 Assemble the four corners of the floor frame using two screws at each corner as shown. At the front corners fasten bolts through from the bottom with nuts on top.

STEP
1




2 Measure the floor frame diagonally. When the diagonal measurements are equal, the floor frame is square.

NOTE

If using a wood platform or concrete slab do not fasten the floor frames to your base at this time. You will anchor the building after it is erected.

When Diagonal Measurements are Equal the Floor Frame is Square.



STEP
2

The floor frame *must be square and level* or holes will not align.

ACV19

- 9196 Right Corner Post (2)
- 9197 Left Corner Post (2)
- Door Track Assembly (1)
- Rear Wall Angle Assembly (1)
- Side Wall Angle Assembly (2)

The remainder of the building assembly requires many hours and more than one person. Do not continue beyond this point if you do not have enough time to complete the assembly today. A partially assembled building can be severely damaged by light winds.

1 Position **right** and **left corner posts** at the corner of the floor frame as shown. The angled end of each post must be placed on top of all 4 corners. Fasten the corner post to the floor frame with 2 screws.


Support the corner posts with stakes or other devices until door jambs are attached.

2 Fasten the **door track assembly**® (holes on top) behind the top of the front corner posts using screws. See the figure.


3 Fasten the **rear wall angle assembly** behind the top of the rear posts using screws.

4 Fasten the **side wall angle assemblies** behind the top of the side posts using screws. Side wall angles overlap rear wall angle in corners.

The floor frame *must be square and level* or holes will not align.



STEP
1



STEP
2

Step 7

G20

● Parts Needed For ● Splice Post/Door Jamb


- 9195 Splice Post (1)
- 9198 Side Splice Post (2)
- 9194 Door Jamb (2)

STEP
1

The door jambs reinforce the door opening and provide an attractive trim. The splice post supports the wall.

1 Position **splice post** at the center of the rear wall and fasten using bolts and nuts into rear wall angle and screws into rear floor frame.


Hint: Measure or count holes to determine if post is centered on rear.




STEP
2

2 Fasten **side splice posts** to the sides of building in the same manner. Angled end of posts must be on top.

3 Fasten the top of the **door jambs** to the door track with 2 screws. Do the same for the bottom into frame. Notched edge faces toward center of building.



STEP
3



Step 8

ACV21


● Parts Needed For ● Studs

● 9199 Siding Stud (6)

The studs provide a surface for attaching the siding panels.

1 Following dimensions, measuring from the ends of angles, place a **stud** between each corner and splice post. Position stud inside top angle and fasten with a screw.

2 Rest bottom tab (large hole) outside floor frame. Do not fasten tab at this time. Repeat procedure for the remaining studs around the building.



Step 9

ACV22

● Parts Needed For ● Side Siding

- 10724 Side Siding (5 Board) (4)
- 10722 Side Siding (3 Board) (4)
- 10723 Side Siding (6 Board) (4)

Each screw in the wall requires a washer.



CORRECT



INCORRECT

1 Slide **side siding** (5 board) into channels of corner and splice posts, flat edge upward, bottom edge down resting on floor frame. Always follow this pattern. Fasten bottom edge and tab of stud to floor frame using screws. Fasten center to stud with screws. Do not fasten flat edge yet.

2 Install **side siding** (3 board) as before. Note how the slot in bottom edge must overlap flat edge of last siding. Fasten both siding panels to stud at this overlap.

3 Install **side siding** (6 board) to the top as before. Remove and reuse screw in angle to fasten top siding.


4 From inside building, fasten siding to corner posts using screws.

5 Repeat steps 1 through 4 for opposite side of building.

NOTE

Be careful to install the correct panel in each position as shown.

The floor frame must be square and level or holes will not align.



Step 10

G23

● Parts Needed For ● Rear/Front Siding

- 8736 Rear Siding (5 Board) (2)
- 5307 Rear Siding (3 Board) (2)
- 5306 Rear Siding (6 Board) (2)
- 8737 Front Siding (5 Board) (2)
- 5291 Front Siding (3 Board) (2)
- 5290 Front Siding (6 Board) (2)

1 Slide **rear siding** (5 board) into channel of corner and splice posts fastening to rear frame as shown in previous step 9.


2 Install **rear siding** (3 board) and **rear siding** (6 board) to complete each section of rear wall. Fasten top center of last siding to rear angle. Remove and reuse screw.

3 Slide **front siding** (5 board) into channels of corner post and door jamb. This siding is fastened from the inside, using screws into post and jamb.

4 Install **front siding** (3 board) and **front siding** (6 board) to complete both front sections.


STEP
1

STEP
2



STEP
3

STEP
4



Step 11

G24et no hdw

● Parts Needed For ● Gable Assemblies

- 8576 Right Gable (2)
- 8577 Left Gable (2)
- 6635 Roof Beam Bracket (4)

STEP
1

The gables go on top of the front and rear walls to support the roof beams.

NOTE


The gables are packed nested together and might be mistaken as one piece. Carefully separate them before continuing.

1 Apply edge trim to the top edge of the right gables and left gables.


2 Attach the four roof beam brackets to the gables using two bolts, washers and nuts.

NOTE

Mounting leg of bracket must face toward center of gable



FRONT



STEP
2



CAUTION:

To avoid mishap on the sharp edge the edge trim must remain in place on the top edge of the gable until right and left roof panels are in place.

Step 12

G25

● Parts Needed For ● Gables/Braces


- Left Gable Assemblies (2)
- Right Gable Assemblies (2)
- 9009 Gable Brace (2)

1 Lift and fasten a right and left gable, under angle at corner, to the rear wall angel with screws.


Hint: On the rear gable, use a bolt and nut at the overlapping rear wall angle. On the front gable, leave out 2 screws closest to center gable leg.

2 Join the left and right gables together with a **gable brace** using a bolt and nut in the second hole from the bottom *only*.

3 Repeat Steps 1 & 2 for the door track on the front of building, except for the **track supports**, fasten as shown.





STEP
1



STEP
2

9009 Gable Brace



Track Supports 6228

STEP
3

Step 13

G26

● Parts Needed For ● Roof Beam/Braces

- Main Roof Beam (1)
- Single Roof Beam (2)
- 9204 Roof Beam Brace (2)

1 Apply the **weather stripping** along the mating edge of the left and right gables as shown. Cut the weather stripping to length.

2 Spread the two halves of the **main roof beam** and fasten the roof beam to the gable brace of the front gable.





3 Fasten the other end of the main roof beam to the gable brace of the rear gable.

4 Fasten the **single roof beams**, *small holes on top*, as shown using bolts and nuts.

5 Fasten a **roof beam brace** to the main roof beam behind the front gable by placing the tab on the end of the brace *between* the roof beams. Align the tab with the *second* hole and fasten the brace with a bolt and nut.

6 Fasten the lower end of the roof beam brace to the **track support** with a bolt and nut.

7 Fasten a **roof beam brace** *between* the rear gable and the roof beam at the *first* hole, as shown.



Step 14

ACV27et

● Parts Needed For ● Right Roof Panel

● 9086 Right Roof Panel (1)


Installing the roof panels is best done with a step ladder. Begin installing roof panels at the back right corner of the building. Each screw and bolt in the roof requires a washer.

NOTE

Measure the building diagonally again and make adjustments to make sure the building is square and level. This will make the roof panels fit better, and holes will align. Don't anchor the floor frame.

NOTE

If a **Roof Beef-Up Kit** was purchased, assemble prior to attaching the roof panels.




1 Locate all the roof panels by their numbers and place them on the ground alongside the building in their proper positions.

2 Position a **right roof panel** at the back right corner and fasten to the top roof beam using screws.

3 Remove edge trim from the left gable under the roof panel.

4 Continue fastening the right roof panel to the gable and lower roof beam using screws, bolts and nuts as shown. Do not fasten the lower end of the panels to the side wall angles at this time.

Hint: Follow the fastener sequence shown for proper alignment.



Step 15

ACV28

● Parts Needed For ● Roof Assembly

- 9087 Left Roof Panel (1)
- 7743 Roof Panel (4)


1 Install a **left roof panel** at the left rear corner of the roof.

2 Install **4 roof panels** in the sequence and positions shown. Follow fastener sequence and instructions in Steps 14 thru 16 while fastening roof panels.



NOTE

Narrow roof panel rib (with bead on it) is always overlapped by wide rib of adjacent panel

3 Cover the joint at the peak with weather stripping tape. Unroll the tape and press it down over the opening at the ridge as you install each roof panel. Do not cut the tape at this time.



FRONT




FRONT

7743 Roof Panel



NOTE

If roof beam holes do not line up with the roof panel holes, shift the building from left to right. If this does not help, your building may not be level. Shim the corners until holes line up.




Step 16

ACV29

● Parts Needed For ● Ridge Caps & Panels


- 6869 Ridge Cap (2)
- 9087 Left Roof Panel (1)
- 9086 Right Roof Panel (1)

1 Install 1 **ridge cap** on the completed roof section using bolts and nuts. Fasten the roof panel rib, **peak cap** and ridge cap together using bolts and nuts.



2 Fasten the remaining **left and right roof panels** as you unroll the weather stripping tape, and press it down, install the second ridge cap overlapping the first ridge cap. Align holes and fasten using bolts and nuts. Fasten the remaining peak cap in the same manner.

3 Fasten the lower end of the panels to the side wall angles using screws and washers. Use bolts and nuts through wall angle overlaps at the bottom of the panel.



Step 17

ACV30

● Parts Needed For ● Roof Trim

● 6015 Side Roof Trim (4)


1 Attach the **side roof trim** to the lower end of the roof panels on each side of the building using screws at each panel overlap.

NOTE

A single screw fastens both trim pieces at the overlap.

2 Using your thumb and index finger, overbend the bottom flange of the side roof trim at the corner inward enough so the right and left roof trim caps fit onto right and left corners.

3 Fasten the roof trim caps to the side trim using a screw.



Step 18

ACV31

● Parts Needed For ● Door Assembly

- 3719 Door Handle Brace (2)
- 10483 Right and Left Door (2)
- 10497 Horizontal Door Brace (4)
- 9202 Vertical Door Brace (2)

The steps on this page tell how to assemble the right door. You will perform exactly the same procedures for the left door. Each bolt and screw in the door requires a washer. Proceed as follows:

1 Attach the **door handle brace** and **handle** to the **door** with 1 bolt as shown. *Don't tighten the bolt yet.*

2 Swing the door handle brace up to the hole in the center of the door and insert a screw.




3 Hold the **vertical door brace** against the center of the inside surface of the door and turn the screw to hold the vertical door brace and door handle brace in place. Fasten to door above and below center connection using 2 screws.

4 Insert a second bolt in the door handle and tighten both bolts.


5 Put a **horizontal door brace** onto the top edge and bottom edge and fasten with 1 bolt in the center.

6 Attach the **lower door guides** and **bolts** as shown.

7 Repeat steps 1 through 6 for the left door.



END VIEW
SHOWING:



Step 19

ACV32

● Parts Needed For ● Door Installation & Adjustment

- Right Door Assembly (1)
- Left Door Assembly (1)

1 From inside the building, put the bottom of the right door assembly (on your left when you are inside the building) behind door jamb into the front frame track.


2 Position the top of the door so that the holes in the door line up with the holes in the door slides.

3 Fasten the door to the door slides using two #10Bx1/2" (13 mm) screws per door slide.




NOTE

The holes in the door slides allow you to adjust the doors. Place the door in the middle holes.


4 Repeat steps 1 through 3 for the left door.



Front Floor Frame Assembly



Adjustment Holes Allow Doors to Meet Evenly Along Their Length



Keep this Owner's Manual and Assembly Instructions for future reference.

Anchoring and Floor Frame


ACV33

Anchoring

Anchor your building at this time.

Floor Frame

If you have purchased a Floor Frame Kit you need to install it at this time.



ALGUNOS DATOS SOBRE EL OXIDO

UR30

ALGUNOS DATOS SOBRE EL OXIDO

La oxidación es un proceso natural que ocurre cuando un metal descubierto está expuesto a la humedad. Areas problemáticas incluyen los agujeros de tornillos, orillas inacabadas, o en donde se originan raspaduras y muescas en la capa protectora durante el ensamblaje normal, manejo, y uso. Identificando estas áreas de oxidación natural y tomando algunas precauciones simples para proteger contra oxidación pueden ayudar para la prevención de oxidación o para repararla al momento que aparezca.

1. Evite dañar y raspar la capa protectora, por dentro y por fuera.
2. Utilice todas las arandelas proveídas. Además de proteger contra el paso del tiempo, las arandelas protegen el metal contra raspaduras hechas por tornillos.
3. Deje el techo, el perímetro del fondo y los rieles de la puerta libre de escombros y hojas que puedan acumular y retener la humedad. Estos pueden hacer daño doble porque emiten ácido mientras se descomponen.
4. Retoque las raspaduras o las muescas de cualquier óxido visible lo más pronto posible. Esté seguro que el exterior está libre de humedad, aceites, o mugre y entonces aplique una capa plana de una pintura de alta calidad.