

General Assembly Guide – Precut Shed & Barn Kits

Step 1: Floor



Optional Wood Floor Kit (not included)

- Pressure-treated 2x4 floor framing, 16" on-center
- 5/8" plywood floor decking
- Upgrade your shed with the optional Floor Kit- see **Recommended Accessories**

or purchase supplies from your local home

Step 2: Walls



Assemble the walls with the pre-cut parts provided.

Step 3: Roof



Install the trusses and sheathing.

Step 4: Shingles



Install drip edge and roof shingles (not included, available at local hardware store).

Disclaimer: Window shown only if included in your precut kit. Check contents before assembly.

Step 5: Windows



Install windows (provided with the kit).

Step 6: Trim



Install the trim included in the kit.

Step 7: Door



Install the door

Step 8: Paint



Your building is primed and ready for paint. Next step... enjoy!

Still have questions? Give us a call at [\(330\) 893-4212](tel:3308934212).