



OUTDOOR STORAGE

MODEL N° 0111

OWNER'S MANUAL

Keep this Identification Number in case you need to contact our Customer Service Department.

REGISTER YOUR LIFETIME PRODUCT TODAY!

There are benefits to registering your Lifetime product. With our new online product registration form, it's fast and easy! Register with us at www.lifetime.com and enjoy these great benefits:

- Receive exclusive money-saving offers from BuyLifetime.com, our online store, as well as NEW product notifications and special closeout promotions!
- In the unlikely event of a product recall or safety modification, we will notify you.
- Registering your product guarantees you warranty service. If you do not register your product, your warranty rights will not be diminished. But you will need to provide a sales receipt to verify your product purchase date before warranty service will be provided.

LIFETIME'S PROMISE TO YOU:

Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.

We invite you to read our privacy policy at www.lifetime.com

REGISTER today!

****U.S. and Canada customers ONLY****

IF ASSISTANCE IS NEEDED,

DO NOT CONTACT THE STORE!

CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)

Call, or visit our Web site for Saturday hours

For customers outside the U.S. or Canada, please contact the store for assistance.



SAFETY INSTRUCTIONS



FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

To ensure safety, do not attempt to assemble this product without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential to reduce the risk of accident or injury.

- Do not use or store hot objects such as grills, blowtorches, welding equipment, etc. near the product.
- If using a ladder during assembly, use extreme caution.
- Two capable adults are required for assembly. (It is also recommended that a third adult function as an instruction reader.)

Most injuries are caused by misuse and/or not following instructions. Use caution when using this product.

STOP!

BEFORE BEGINNING ASSEMBLY

STOP!



Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.



Identify and inventory all parts and hardware using the parts and hardware lists and identifiers in this document.



TOOLS REQUIRED FOR ASSEMBLY



Phillips Screwdriver

Safety Glasses

Electric Drill

Measuring Tape

1/4" Drill Bit



(1)

(1 for each person)

ASSEMBLY GUIDES

Refer to the following areas throughout the instructions to assist in the assembly process:


This area is located at the top, left-hand corner of the page and indicates which tools and hardware are needed to complete the assembly steps on a page.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



This area is located at the top, right-hand corner of the page and shows an image of the product with shaded parts indicating which section is being assembled.



This area is usually located in the bottom, left-hand corner of a step and indicates that special attention is needed to perform a particular part of a step.



Note:

These areas are usually located in the bottom, right-hand corner of a step and indicate that damage to the product or serious injury may occur if the caution or warning is not heeded.




CAUTION



WARNING

Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.



ADZ (x10)
1/4" x 5/8" Pan-Head Screw


PARTS & HARDWARE LIST

ID	Description	Quantity	✓
Main Parts			
AYI	Shutter	2	<input type="checkbox"/>
BJI Shutter Hardware Bag			
ADS	1/4" x 3/4" Phillips Pan-Head Screw	8	<input type="checkbox"/>

HARDWARE IDENTIFIER

SHUTTER HARDWARE BAG [BJI]

Hardware is shown at actual size




ADS (x8)

1/4" x 3/4" Phillips Pan-Head Screw

PARTS IDENTIFIER

Part shown at 10% of actual size



AYI (x2)

Shutter




Note: Identify the size of your shed (8' or 11'), and then use the correct section. 8' Shed instructions start on page 6. 11' Shed instructions start on page 9.



Note: Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



NO HARDWARE REQUIRED FOR THIS PAGE

SEC 1




SEC

1.1

SHUTTER INSTALLATION FOR 8' SHEDS


Below is a map of potential screw hole locations. You will use these locations in the next step. Some sheds will have small bumps molded into the plastic at the locations shown. If there are no bumps, measure carefully before drilling in the next step. The left-side holes are found in the first and third grooves, counting from the left wall seam. The right side holes are in the first and third grooves, counting from the right wall seam.






TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

1/4" Drill Bit



NO HARDWARE REQUIRED FOR THIS PAGE


SEC 1



SEC


1.2

Use a 1/4" Drill Bit to drill holes from the inside of the shed at the locations shown. Refer to previous step for measurements.



Left Wall Panel



Window Panel located here



Right Wall Panel




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADS (x8)

SEC 1




SEC

1.3

Look at the diagrams below and the holes at the top and the bottom of the shutter to determine which set you should use.


Have one person line up the correct holes in the back of the shutters, with the holes that you pre-drilled. A second person, inside the shed will insert a **1/4" x 3/4" Phillips Pan-Head Screw (ADS)** through the shed and into the **Shutter (AYI)**. Do this for each of your pre-drilled holes.



Back of Shutter

Use hole #2 (the far left hole in each grouping) for this shutter.


Use hole #1 (the far right hole in each grouping) for this shutter.



Outside of Shed




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



NO HARDWARE REQUIRED FOR THIS PAGE

SEC 2




SEC

2.1

SHUTTER INSTALLATION FOR 11' SHEDS


Below is a map of potential screw hole locations. You will use these locations in the next step. Some sheds will have small bumps molded into the plastic at the locations shown. If there are no bumps, measure carefully before drilling in the next step. The Left side holes are found in the second and fourth grooves, counting from the left wall seam. The right side holes are in the first and third grooves, counting from the right wall seam.






TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


SEC 2



1/4" Drill Bit




NO HARDWARE REQUIRED FOR THIS PAGE



SEC


2.2

Use a 1/4" Drill Bit to drill holes from the inside of the shed at the locations shown. Refer to previous step for measurements.



Left Wall Panel




Window Panel located here



Right Wall Panel




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADS (x8)

SEC 2




SEC

2.3


Look at the diagrams below and the holes at the top and bottom of the shutter to determine which set you should use.

Have one person line up the correct holes in the back of the shutters, with the holes that you pre-drilled. A second person, inside the shed will insert a **1/4" Phillips Pan-Head Screw (ADS)** through the shed and into the **Shutter (AYI)**. Do this for each of your pre-drilled holes.



Back of Shutter

Use hole N° 3 (the center hole in each grouping) for this shutter.



Use hole N° 3 (the center hole in each grouping) for this shutter.

Outside of Shed

LIFETIME OUTDOOR SHED EQUIPMENT

10-YEAR LIMITED FACTORY WARRANTY

THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.

1. Lifetime outdoor sheds are warranted to the original purchaser to be free from defects in material or workmanship for a period of ten years from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.
2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the shed or its components are not covered under this warranty.
3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the truss will void this warranty.
4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.
6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to extent permitted by Federal and state law. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY A SALES RECEIPT.

REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010
or call (800) 225-3865 M-F 7 a.m. to 5 p.m. MST.

Please include your dated sales receipt and photographs of damaged parts.

To register the product, visit our Web site at www.lifetime.com



www.lifetime.com

©2004 Lifetime Products, Inc.

PO Box 160010 • Freeport Center, Bldg. D-11 Clearfield, Utah 84016-0010
T: 800-225-3865 • F: 801-728-1907

ENHANCE YOUR LIFETIME® PURCHASE BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS

To purchase accessories or other Lifetime Products, visit us at:

www.lifetime.com

Or call: 1-800-424-3865

