



OUTDOOR STORAGE

MODEL N° 6415

OWNER'S MANUAL

Keep this Identification Number in case you must contact our Customer Service Department.

IMPORTANT! PLEASE READ BEFORE BEGINNING ASSEMBLY

Dear Valued Customer,

We would like to congratulate you on your purchase of a Lifetime® Outdoor Storage Shed! We are confident that you have made the perfect choice and you will be very pleased with your new storage solution.

Lifetime® Outdoor Storage is part of the family of products created and manufactured by Lifetime® Products, Inc. Like all of our products, you can be assured that the quality of your Lifetime Outdoor Storage Shed is the best in the world! And, we back that quality up by offering the best warranty in the business – A 10-year warranty that fully covers the Shed!

All of our Sheds are built with the highest-quality steel and high-density polyethylene (HDPE) parts. The design and construction of our steel-reinforced double-Wall Panels is second to none. All of our exposed steel parts and gables are powder coated and we use high-density polyethylene plastic. What makes polyethylene so special? It has superior strength and durability, and, it won't crack or degrade outdoors.

So now that you know the quality you are getting in a Lifetime Outdoor Storage Shed, please take the time to **READ THIS INSTRUCTION MANUAL!**

We have taken great care in providing the best possible form of instructions to help you put your new Outdoor Storage Shed together. Before you get started, **PLEASE** read the following preparation tips to help you get started!

We can assure you, your construction experience will be a lot more enjoyable if you do!

PREPARATION TIPS:

- The first step is simple... **RELAX!** You have made a great purchase, but Rome was not built in a day. Plan to spend a good part of your weekend putting together your fine Outdoor Storage Shed. Our philosophy is, if it comes together quickly and easily, it surely will come apart quickly and easily! Your Lifetime® Outdoor Storage Shed will surely last a long, long time, if you are patient, and take all the time necessary to put it together as we have instructed.
- Grab a friend to join in on the fun! This is not a one-person endeavor. We have found that not only will things go smoother if you have two or more people participating in the construction of the Shed, but it will go quicker as well. So, the more the merrier!
- Make sure you have all the tools necessary for constructing your new Shed. There is a "Tools Required For This Assembly" list on page five of this Owner's Manual.
- The plastic pieces of your Shed may become damaged by over tightening the screws. To avoid this damage, we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low-torque setting. If neither is available, use a hand screwdriver. If a hand screwdriver is all you have, take several breaks... your wrist will need it!
- You will also need two small ladders (when it comes time to do the roof!).

IMPORTANT! PLEASE READ BEFORE BEGINNING ASSEMBLY

- Before beginning assembly, remove the Parts List from the center of this Owner's Manual and take an inventory of the parts included with your Outdoor Storage Shed. Also, read through the entire instruction manual. It's always a great practice to get a feel for the flow of the process and to familiarize yourself with the parts involved. But, try not to get ahead of yourself and start the process out of order.
- **FOLLOW THE INSTRUCTIONS IN ORDER!** Everything goes together in a certain order, and we have learned what that correct order should be. In our state-of-the-art research and testing facility, we have painstakingly created these instructions. The order of construction is there for a reason, and some parts simply will not fit if built out of order. Just follow along with the order in the instructions and everything will fit together and things will go very smooth.
- **YOUR SHED MUST BE BUILT ON A LEVEL SURFACE!** If the spot you have chosen to place your wonderful new Outdoor Storage Shed is not level, the Shed will not assemble correctly! We recommend a concrete patio, a wood platform or creating a pad with pea gravel. Your Shed is meant to last a lifetime, so provide the proper foundation for it before you start to build.
- Before you build it, make sure you are allowed to build it! Consult all building codes, as well as city and county ordinances, to ensure that you do not require a building permit to construct your Outdoor Storage Shed. Proper building permit documentation may be required in your neighborhood, and it would be quite unfortunate to learn this after your Outdoor Storage Shed is already built!

Now that you're ready to begin the construction of your wonderful new Outdoor Storage Shed, step back, take a deep breath, get yourself a large cold beverage and enjoy yourself. We guarantee that after spending the right amount of time in building your Shed, you will be able to enjoy it for years to come.

Thanks for choosing Lifetime®, and have fun!

ABOUT LIFETIME PRODUCTS, INC.

Lifetime Products, Inc., has applied innovation and cutting-edge technology in plastics and metals to create a family of affordable lifestyle products that feature superior strength and durability. The world's leading manufacturer of folding tables and chairs, Lifetime was founded in 1986 as the maker of portable basketball systems that revolutionized the industry with patented technology. With diverse offerings such as outdoor storage sheds and steel utility trailers, Lifetime continues to develop innovative products that outfit the way you live.

Lifetime makes the things you need for the lifestyle you want. By innovating products in and around the home, Lifetime simplifies your everyday life and enables you to get the most out of your free time.



REGISTER YOUR LIFETIME PRODUCT TODAY!

There are benefits to registering your Lifetime product. With our new online product registration form, it's fast and easy! Register with us at www.lifetime.com and enjoy these great benefits:

- Receive exclusive money-saving offers from BuyLifetime.com, our online store, as well as NEW product notifications and special closeout promotions!
- In the unlikely event of a product recall or safety modification, we will notify you.
- Registering your product guarantees you warranty service. If you do not register your product, your warranty rights will not be diminished. But you will need to provide a sales receipt to verify your product purchase date before warranty service will be provided.

LIFETIME'S PROMISE TO YOU:

Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.

We invite you to read our privacy policy at www.lifetime.com

REGISTER today!

****U.S. and Canada customers ONLY****

IF ASSISTANCE IS NEEDED,

DO NOT CONTACT THE STORE!

CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)

Call, or visit our Web site for Saturday hours

For customers outside the U.S. or Canada, please contact the store for assistance.



SAFETY INSTRUCTIONS



FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

To ensure safety, do not attempt to assemble this product without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential to reduce the risk of accident or injury.

- Do not use or store hot objects such as grills, blowtorches, welding equipment, etc. near the product.
- If using a ladder during assembly, use extreme caution.
- Two capable adults are required for assembly. (It is also recommended that a third adult function as an instruction reader.)

Most injuries are caused by misuse and/or not following instructions. Use caution when using this product.


BEFORE BEGINNING ASSEMBLY



Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.



Read the "Congratulations" letter on page 2-3. Identify and inventory all parts and hardware using the parts and hardware lists and identifiers in this document.



****Two adults required to complete assembly****
(+ one adult suggested as an instruction reader)

Only adults should set up the product. Do not allow children in the set-up area until assembly is complete.



TOOLS REQUIRED FOR ASSEMBLY

7/16"



(2)

3/8"



(1)

Adjustable



(1)

Rubber Mallet



(1)

Box Knife



(1)

Phillips
Screwdriver



(1)

3/16" Masonry
Bit



(1)

Level



(1)

2" x 4" x 11'
Leveling Board



(1)

6' Ladder



(2)

Power Drill*



(1)

Work Light



(1)

Pliers



(1)

Flashlight



(1)

Hammer Drill*



(1)

Safety Glasses



(1 for each person)

*See "Screwdriver Notice" on page 7.

ASSEMBLY GUIDES

Refer to the following areas throughout the instructions to assist in the assembly process:

This area is located at the top, left-hand corner of the page and indicates which tools and hardware are needed to complete the assembly steps on a page.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

This area is located at the top, right-hand corner of the page and shows an image of the product with shaded parts indicating which section is being assembled.

SES #

This area is usually located in the bottom, left-hand corner of a step and indicates that special attention is needed to perform a particular part of a step.



Note:

These areas are usually located in the bottom, right-hand corner of a step and indicate that damage to the product or serious injury may occur if the caution or warning is not heeded.



CAUTION



WARNING

Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.



ADZ (x10)
1/4" x 5/8" Pan-Head Screw

IMPORTANT NOTICES

Level Surface Notice:

Surface must be leveled before installation. We recommend building a level work space with a concrete or patio style surface. If the surface is not properly leveled, the Outdoor Shed will not assemble correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.

Building Code Notice:

Consult all local building codes, as well as city and county ordinances, to ensure that the construction of the Outdoor Shed does not require a building permit. Proper building permit documentation may be required in your neighborhood, and it would be unfortunate to learn this after constructing the Shed.

Screwdriver Notice:

You may use a #2 Phillips head screwdriver bit and a power screwdriver or drill, instead of a hand screwdriver. However, be aware that the plastic pieces of your Shed can be damaged by overtightening of screws. To avoid damage we strongly recommend the use of a low-powered power screwdriver or a drill that has an adjustable clutch that is set on a low torque setting. If neither is available, use a hand screwdriver. In any case use caution to avoid overtightening the screws.

Floor Puncture Notice:

Sharp objects may damage your floor. If resting sharp, heavy objects on your Shed floor, place a block of wood between the sharp object and floor.



CAUTION:

If more than six (6) inches of snow accumulate on the roof of the shed, carefully remove the snow to avoid possible roof collapse. While standing on the ground, remove the snow from the roof with a broom or snow shovel. Do not stand on the roof to remove snow.

Snow Load Kit available from Customer Service for high snow areas.

PARTS & HARDWARE LIST

BOX 1

ID	Description	Qty
BUA METAL PARTS KIT		
AFQ	Wall Support Channel	8
AFG	Truss Brace Channel	1
AFC	Door End Channel	2
AFR	Corner Channel	4
AFD	Door Header Channel	1
AFH	Truss Gutter Channel	2
AFP	Truss Support Strip	2
AFJ	Long Wall Support Channel Extension	2
AFN	Short Wall Support Channel Extension	4
BTI DOOR HINGE PARTS KIT		
AFK	Right Hinge Assembly	1
AFI	Left Hinge Assembly	1
PLASTIC & MISCELLANEOUS PARTS		
AFS	10" x 30" Shelf	5
AGU	Outer Roof Panel "A"	2
AGV	Outer Roof Panel "B"	2
AFT	14" x 30" Shelf	2
AGH	Gable Half 1	2
AGI	Gable Half 2	2
AGS	Outer Floor Panel "A"	2
AGT	Outer Floor Panel "B"	2
AGE	End Roof Cap	2
AFF	Gable Truss Brace	2
AFB	Door Brace	6
BTH BOX 1 SHED PARTS BOX		
AFU	Pegboard Strip	2
AIZ	14" Shelf Bracket	4
AHA	Roof Cap Cover	2
BKB Left Door Assembly Hardware		
AHZ	Left Door Handle	1
AHM	Dead Bolt Latch	2
AIA	Left Door Lock Bracket	1
AIB	Left Door Strike Plate	1
ADZ	1/4" x 5/8" Pan-Head Screw	9
ADX	#10 x 1/2" Pan-Head Screw	3
AEE	#10 x 1/2" Flat Washer	3
ACH	1/4" x 1 1/2" Carriage Bolt	2
ADJ	1/4" Cap Nut	2
BKC Right Door Assembly Hardware		
AIK	Right Door Handle	1
AIO	Thumb Lever	1
AHV	Door Latch	1
AIL	Right Door Lock Bracket	1
AHX	Latch Cover Plate	1
AHW	Latch Block	1
ADZ	1/4" x 5/8" Pan-Head Screw	9
ADW	#10 x 3/4" Pan-Head Screw	4
AEE	#10 x 1/2" Flat Washer	3
ADB	3/8" x 1/2" Steel Spacer	2
AHY	Latch Spring	1
ACI	1/4" x 2" Carriage Bolt	2
AAB	1/4" Centerlock Nut	2
AEB	1/4" Flat Washer	2
BMX Wall Panel Installation Hardware		
ADZ	1/4" x 5/8" Pan-Head Screw	116
ADC	#2 Phillips Bit	1

BOX 1 (CONT.)

ID	Description	Qty
BNA Gable Assembly Hardware (x2)		
AGP	Louvered Vent	1
AIQ	Vent Screen	1
ADW	#10 x 3/4" Pan-Head Screw	5
AEE	#10 x 1/2" Flat Washer	5
ADZ	1/4" x 5/8" Pan-Head Screw	4
BHC Pegboard Strip Installation Hardware		
ADW	#10 x 3/4" Pan-Head Screw	10
BHD Tool Clip Assortment		
AIF	2" Double-Arm Hook	1
AIG	4" Double-Arm Hook	1
AIL	L-Hook	3
AIH	J-Hook	3
AIJ	Tool Holder	2
BKD Door & Entry Gable Installation		
ADZ	1/4" x 5/8" Pan-Head Screw	24
ACH	1/4" x 1 1/2" Carriage Bolt	4
ACA	1/4" x 1/2" Carriage Bolt	4
ADJ	1/4" Cap Nut	8
ADX	#10 x 1/2" Pan-Head Screw	2
AEB	1/4" Flat Washer	4
AHL	Dead Bolt Strike Plate	1
AHN	Floor Bracket	2
BND Trim Installation Hardware		
AGA	Corner Trim Bracket	24
AHQ	Door Trim Bracket	4
AHR	Door Trim Clip	2
ADX	#10 x 1/2" Pan-Head Screw	56
ACK	#8 x 1" Pan-Head Screw	4
SHELF INSTALLATION HARDWARE		
BHH 10" x 30" Shelf Installation Hardware (x5)		
ADX	#10 x 1/2" Pan-Head Screw	14
AIY	10" Shelf Bracket	2
BMV 14" x 30" Shelf Installation Hardware (x2)		
ADX	#10 x 1/2" Pan-Head Screw	4
AEE	#10 Flat Washer	4
BTM Door Spacing Adjustment Hardware		
ADZ	1/4" x 5/8" Pan-Head Screw	4

BOX 2

BNL BOX 2 METAL PARTS KIT 1

AFG	Truss Brace Channel	2
AFH	Truss Gutter Channel	4
AFP	Truss Support Strip	4

BNK BOX 2 METAL PARTS KIT 2

AFQ	Wall Support Channel	4
-----	----------------------	---

PLASTIC & MISCELLANEOUS PARTS

AFY	Center Roof Cap	2
AGQ	Inner Roof Panel	3
AHB	Inner Roof Panel for Domed Skylight	1
AHD	Wall Panel	3
AGB	Domed Skylight	1
AHH	Window Wall Panel	1
AHG	Window Frame	2
AGJ	Inner Floor Panel	4
AHF	Window	2
AFL	Roof Support Strip	12

PARTS & HARDWARE LIST

BOX 2 (CONT.)

ID	Description	Qty
CJV	BOX 2 SHED PARTS BOX	
BGV	Truss Assembly Hardware (x5)	
ADJ	1/4" Cap Nut	10
AAK	1/4" x 1 1/2" Hex Bolt	10
AHK	Truss Connector	1
AHT	Floor Bracket	2
CJW	Truss & Wall/Shelf Support Channel Installation Hardware	
ADZ	1/4" x 5/8" Pan-Head Screw	128
AAK	1/4" x 1 1/2" Hex Bolt	18
ADJ	1/4" Cap Nut	18
AHT	Floor Bracket	6
CJX	Roof & Rear Gable Installation Hardware	
ADZ	1/4" x 5/8" Pan-Head Screw	220
ACJ	#10 x 5/8" Pan-Head Screw	16
AED	#10 x 1" Fender Washer	16
ADX	#10 x 1/2" Pan-Head Screw	4
ACF	#10 x 5/16" Pan-Head Screw	1
ADK	#10 Cap Nut	1
AJA	Foam Cube	20

BOX 3

BNL BOX 2 METAL PARTS KIT 1

AFG	Truss Brace Channel	2
AFH	Truss Gutter Channel	4
AFP	Truss Support Strip	4

BNK BOX 2 METAL PARTS KIT 2

AFQ	Wall Support Channel	4
-----	----------------------	---

PLASTIC & MISCELLANEOUS PARTS

AFY	Center Roof Cap	2
AGQ	Inner Roof Panel	3
AHB	Inner Roof Panel for Domed Skylight	1
AHD	Wall Panel	3
AGB	Domed Skylight	1
AHH	Window Wall Panel	1
AHG	Window Frame	2
AGJ	Inner Floor Panel	4
AHF	Window	2
AFL	Roof Support Strip	12

BNB BOX 3 SHED PARTS BOX

BGU Window Assembly & Installation Hardware (x2)

ADZ	1/4" x 5/8" Pan-Head Screw	4
ADW	#10 x 3/4" Pan-Head Screw	4
ADX	#10 x 1/2" Pan-Head Screw	22
AEE	#10 x 1/2" Flat Washer	2
ACF	#10 x 5/16" Pan-Head Screw	2
ACB	#10 x 1 1/4" Pan-Head Screw	4
ACD	#10 x 3/8" Flat-Head Screw	2
ADK	#10 Cap Nut	2
AIE	Mounted Window Stay	2
AIN	Sliding Window Stay	2
AIV	Window Stay Bracket	2
AIR	Window Hinge Tube	4
AIU	Window Latch Bearing	4
AIT	Window Latch	4

BOX 3 (CONT.)

ID	Description	Qty
BEC	Domed Skylight Assembly Hardware (x2)	
ACR	#10 x 5/8" Carriage Bolt	12
ADK	#10 Cap Nut	12
AEE	#10 x 1/2" Flat Washer	12
AHI	Butyl Tape	1

BOX 4

PLASTIC & MISCELLANEOUS PARTS


AHD	Wall Panel	8
AGZ	Right Door	1
AGO	Left Door	1
AQX	Corner Trim Piece	4
AGC	Door Top Trim	1
AGD	Door Side Trim	2

PARTS IDENTIFIER

BOX 1

BOX 1 METAL PARTS KIT [BUA]


Parts shown at 8% of actual size




AFQ (x8)
Wall/Shelf Support Channel




AFG (x1)
Truss Brace Channel




AFC (x2)
Door End Channel




AFR (x4)
Corner Channel




AFD (x1)
Door Header Channel




AFH (x2)
Truss Gutter Channel



AFP (x2)
Truss Support Strip



AFJ (x2)
Long Wall Support Channel Extension



AFN (x4)
Short Wall Support Channel Extension

DOOR HINGE PARTS KIT [BTI]

Parts shown at 8% of actual size



AFI (x1)
Left Hinge Assembly




AFK (x1)
Right Hinge Assembly


BOX 1 (CONT.)

PLASTIC & MISCELLANEOUS PARTS


Parts shown at 4% of actual size




AFS (x5)
10" x 30" Shelf




AFT (x2)
14" x 30" Shelf




AGS (x2)
Outer Floor Panel "A"




AGT (x2)
Outer Floor Panel "B"




AGH (x2)
Gable Half 1




AGI (x2)
Gable Half 2




AGU (x2)
Outer Roof Panel "A"




AGV (x2)
Outer Roof Panel "B"



AGE (x2)
End Roof Cap



AFF (x2)
Gable Truss Brace



AFB (x6)
Door Brace


! Note: Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.

PARTS & HARDWARE IDENTIFIER

BOX 1 (CONT.)

BOX 1 SHED PARTS BOX [BTH]


Parts shown at 15% of actual size (*Unless otherwise noted)



AFU (x2)
Pegboard Strip



AIZ (x4)
14" Shelf Bracket



AHA (x2)
Roof Cap Cover

LEFT DOOR ASSEMBLY HARDWARE [BKB]

Hardware shown at actual size (*Unless otherwise noted)



***AHZ** (x1)
Left Door Handle



***AHM** (x2)
Deadbolt Latch



ACH (x2)
1/4" x 1 1/2" Carriage Bolt



ADX (x3)
#10 x 1/2" Pan-Head Screw



AEE (x3)
#10 x 1/2" Flat Washer




ADJ (x2)
1/4" Cap Nut



***AIA** (x1)
Left Door Lock Bracket



***AIB** (x1)
Left Door Strike Plate



ADZ (x9)
1/4" x 5/8" Pan-Head Screw

RIGHT DOOR ASSEMBLY HARDWARE [BKC]

Hardware shown at actual size (*Unless otherwise noted)



***AIK** (x1)
Right Door Handle



ACI (x2)
1/4" x 2" Carriage Bolt




AEE (x3)
#10 x 1/2" Flat Washer
(Only 3 are used)



ADB (x2)
3/8" x 1/2" Steel Spacer



AAB (x2)
1/4" Centerlock Nut



AHY (x1)
Latch Spring



***AHW** (x1)
Latch Block



***AIO** (x1)
Thumb Lever



ADW (x4)
#10 x 3/4" Pan-Head Screw



AEB (x2)
1/4" Flat Washer



***AHX** (x1)
Latch Cover Plate



***AHV** (x1)
Door Latch



***AIL** (x1)
Right Door Lock Bracket



ADZ (x9)
1/4" x 5/8" Pan-Head Screw

PARTS & HARDWARE IDENTIFIER


BOX 1 (CONT.)

WALL PANEL INSTALLATION HARDWARE [BMX]

Hardware shown at actual size




ADZ (x116)
1/4" x 5/8" Pan-Head Screw (Not all screws are used)




ADC (x1)
#2 Phillips Bit

GABLE ASSEMBLY HARDWARE [BNA] (x2)


Hardware shown at actual size



AGP (x1)
Louvered Vent



AIQ (x1)
Vent Screen



ADZ (x4)
1/4" x 5/8" Pan-Head Screw



ADW (x5)
#10 x 3/4" Pan-Head Screw



AEE (x5)
#10" x 1/2" Pan-Head Screw

PEGBOARD STRIP INSTALLATION HARDWARE [BHC]


Hardware shown at actual size




ADW (x10)
#10 x 3/4" Pan-Head Screw

Tool Clip Assortment [BHD]


Hardware shown at 50% of actual size




AIG (x1)
4" Double-Arm Hook



AIF (x1)
2" Double-Arm Hook



AII (x3)
L-Hook



AIH (x3)
J-Hook



AIJ (x2)
Toolholder

PARTS & HARDWARE IDENTIFIER

BOX 1 (CONT.)

DOOR & ENTRY GABLE INSTALLATION HARDWARE [BKD]

Hardware shown at actual size (*Unless otherwise noted)



ADZ (x24)
1/4" x 5/8" Pan-Head Screw



ACH (x4)
1/4" x 1 1/2" Carriage Bolt



***AHL (x1)**
Dead Bolt Strike Plate




***AHN (x2)**
Floor Bracket



ADX (x2)
#10 x 1/2" Pan-Head Screw



ADJ (x8)
1/4" Cap Nut




ACA (x4)
1/4" x 1/2" Carriage Bolt




AEB (x4)
1/4" Flat Washer

TRIM INSTALLATION HARDWARE [BND]

Hardware shown at actual size (*Unless otherwise noted)



***AGA (x24)**
Corner Trim Bracket




***AHQ (x4)**
Door Trim Bracket



***AHR (x2)**
Door Trim Clip



ADX (x56)
#10 x 1/2" Pan-Head Screw



ACK (x4)
#8 x 1" Pan-Head Screw

SHELF INSTALLATION HARDWARE

Hardware shown at actual size (*Unless noted otherwise)

14" x 30" Shelf Hardware [BMY] (x2)



ADX (x4)
#10 x 1/2" Pan-Head Screw



AEE (x4)
#10 Flat Washer

10" x 30" Shelf Hardware [BHH] (x5)




ADX (x14)
#10 x 1/2" Pan-Head Screw
(Not all are used)



***AIY (x2)**
10" Shelf Bracket

DOOR SPACING ADJUSTMENT HARDWARE [BTM]

Hardware shown at actual size




ADZ (x4)
1/4" x 5/8" Pan-Head Screw

PARTS IDENTIFIER

BOX 2


BOX 2 METAL PARTS KIT 1 [BNL]

Parts shown at 8% of actual size




AFG (x2)

Truss Brace Channel



AFH (x4)

Truss Gutter Channel




AFP (x4)

Truss Support Strip

BOX 2 METAL PARTS KIT 2 [BNK]

Parts shown at 8% of actual size




AFQ (x4)

Wall/Shelf Support Channel


PLASTIC & MISCELLANEOUS PARTS

Parts shown at 4% of actual size




AGQ (x3)

Inner Roof Panel




AHD (x3)

Wall Panel



AHB (x1)

Inner Roof Panel for Domed Skylight



AHH (x1)


Window Wall Panel

PARTS IDENTIFIER

BOX 2 (CONT.)

PLASTIC & MISCELLANEOUS PARTS (CONT.)


Parts shown at 4% of actual size



AGJ (x4)


Inner Floor Panel

Parts shown at 8% of actual size




AFY (x2)

Center Roof Cap



AGB (x1)


Domed Skylight



1004595


AHG (x2)

Window Frame



AHF (x2)

Window



AFL (x12)

Roof Support Strip

PARTS & HARDWARE IDENTIFIER

BOX 2 (CONT.)


BOX 2 SHED PARTS BOX [CJV]

TRUSS ASSEMBLY HARDWARE [BGV] (x5)

Hardware shown at actual size (*Unless otherwise noted)




ADJ (x10)
1/4" Cap Nut



AAK (x10)
1/4" x 1 1/2" Hex Bolt



***AHT** (x2)
Floor Bracket




***AIP** (x1)
Truss Connector

TRUSS & WALL/SHELF SUPPORT CHANNEL ASSEMBLY INSTALLATION HARDWARE [CJW]

Hardware shown at actual size (*Unless otherwise noted)



ADZ (x128)
1/4" x 5/8" Pan-Head Screw



AAK (x18)
1/4" x 1 1/2" Hex Bolt



ADJ (x18)
1/4" Cap Nut



***AHT** (x6)
Floor Bracket

ROOF & REAR GABLE INSTALLATION HARDWARE [CJX]

Hardware shown at actual size (*Unless otherwise noted)




ADZ (x220)
1/4" x 5/8" Pan-Head Screw
(Not all screws will be used)



***AJA** (x20)
Foam Cube
(Not all are used)



ADK (x1)
#10 Cap Nut




ACJ (x16)
#10 x 5/8" Pan-Head Screw



ACF (x1)
#10 x 5/16" Pan-Head Screw



ADX (x4)
#10 x 1/2" Pan-Head Screw




AED (x16) #10 x 1"
Fender Washer

PARTS IDENTIFIER

BOX 3


BOX 3 METAL PARTS KIT 1 [BNL]

Parts shown at 8% of actual size




AFG (x2)

Truss Brace Channel



AFH (x4)

Truss Gutter Channel




AFP (x4)

Truss Support Strip

BOX 3 METAL PARTS KIT 2 [BNK]

Parts shown at 8% of actual size




AFQ (x4)

Wall/Shelf Support Channel

PLASTIC & MISCELLANEOUS PARTS


Parts shown at 4% of actual size



1000476

AGQ (x3)

Inner Roof Panel



1015533

AHB (x1)


Inner Roof Panel for Domed Skylight



1000272

AHD (x3)

Wall Panel



100XXXX


AHH (x1)

Window Wall Panel

BOX 3 (CONT.)

PLASTIC & MISCELLANEOUS PARTS (CONT.)


Parts shown at 4% of actual size



AGJ (x4)


Inner Floor Panel

Parts shown at 8% of actual size




AFY (x2)

Center Roof Cap




AGB (x1)

Domed Skylight




AHG (x2)

Window Frame



AHF (x2)

Window



AFL (x12)

Roof Support Strip

PARTS & HARDWARE IDENTIFIER

BOX 3 (CONT.)

BOX 3 SHED PARTS BOX [BNB]

WINDOW INSTALLATION HARDWARE [BGU] (x2)

Hardware shown at actual size (*Unless otherwise noted)



ADZ (x4)
1/4" x 5/8" Pan-Head Screw



ADW (x4)
#10 x 3/4" Pan-Head Screw



ADX (x22)
#10 x 1/2" Pan-Head Screw



ACF (x2)
#10 x 5/16" Pan-Head Screw




AEE (x2)
#10 Flat Washer



ADK (x2)
#10 Cap Nut



ACB (x4)
#10 x 1 1/4" Pan-Head Screw




ACD (x2)
#10 x 3/8" Flat-Head Screw



***AIE (x2)**
Mounted Window Stay



***AIN (x2)**
Sliding Window Stay



***AIV (x2)**
Window Stay Bracket



***AIU (x4)**
Window Latch Bearing



***AIT (x4)**
Window Latch



***AIR (x4)**
Window Hinge Tube

DOMED SKYLIGHT ASSEMBLY HARDWARE [BEC] (x2)

Parts shown at 8% of actual size



ACR (x12)
#10 x 5/8" Carriage Bolt



ADK (x12)
#10 Cap Nut



AEE (x12)
#10 Flat Washer




AHI (x1)
Butyl Tape

PARTS IDENTIFIER

BOX 4

PLASTIC & MISCELLANEOUS PARTS


Parts shown at 4% of actual size



1001790

AGO (x1)

Left Door



1001787

AGZ (x1)


Right Door



1000272

AHD (x8)

Wall Panel




AGC (x1)

Top Door Trim



AGD (x2)

Side Door Trim



AQX (x4)

Corner Trim



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 1



Concrete (1.5 cu. yd.)




SEC

1.1

SITE PREPARATION - CONCRETE PLATFORM PREPARATION

The actual dimensions of your shed (at its widest and longest points) are 11' x 13'6". Ensure you select a site that will accommodate these measurements. The base of the shed is slightly smaller than this, so you will need to create a level surface that is at least 123 1/2" x 153 1/2". We recommend using a level cement or patio style surface. This will provide the best long-term performance for your shed.

! Note: Shed Extension Kits are available for this shed. Please consider possible shed expansion when planning the site for your shed. See back cover of this manual for information on ordering accessories.



! Note: Surface must be leveled before installation. If the surface is not properly leveled, the Outdoor Shed will not assemble or function correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.

! Note: Any platform or similar structure should be built above ground in order to avoid water pooling inside the Shed.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



2" x 4" x 153 1/2" (x2) (Not included)



2" x 4" x 120 1/2" (x11) (Not included)



16d 3" Common Nail (x44) (Not included)

SEC 1



SEC



1.2

ALTERNATIVE SITE PREPARATION: OPTION 1 - WOOD PLATFORM ASSEMBLY

Ensure all lumber used is treated and approved for outdoor use. Build outside frame to 123 1/2" x 153 1/2" outside dimensions:



Note: Whenever possible, you should use the surfaces described on Page 7. When this is not possible, we recommend you use a wood platform or a filled wood frame.



To be sure to have studs in the correct location to nail plywood in the next step, start measuring from outside edge of first board 16" to the center of the second. Then measure the remaining boards from center to center.



Note: All lumber must be rated for outdoor use.



Note: Surface must be leveled before installation. If the surface is not properly leveled, the Outdoor Shed will not assemble or function correctly. Proper surface leveling will save you time in the long run, so please do not ignore this step.

Place the 2" x 4" x 120 1/2" boards on the inside of the frame. Nail each board in place with the 16d nails.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 1




48" x 96" x 3/4" Treated Plywood (x3)
(Not included)



27 1/2" x 96" x 3/4" Treated Plywood (x1)
(Not included)



27 1/2" x 57 1/2" x 3/4" Treated Plywood (x1) (Not included)



9 1/2" x 96" x 3/4" Treated Plywood (x1) (Not included)

8d 1 1/2" Common Nail (x70)
(Not included)




SEC

1.3

ALTERNATIVE SITE PREPARATION: OPTION 1 - WOOD PLATFORM ASSEMBLY (CONT)

Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B.



Note: All lumber must be rated for outdoor use.

SEC

1.4

Cut Plywood into sizes called for below. Arrange the Plywood according to the diagram and nail into place with 8d x 1 1/2" nails. Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt until platform is stable. Drill three evenly spaced 1/2" drain holes in plywood between each 2" x 4" joist.

Front of Shed		27 1/2" x 96"		27 1/2" x 57 1/2"	
		48" x 96"	48" x 96"	48" x 96"	9 1/2" x 96"



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 1



2" x 4" x 153 1/2" (x2) (Not included)



2" x 6" x 116 1/2" (x2) (Not included)



8d 1 1/2" Common Nail (x16)
(Not included)



Pea Gravel (17 Cubic Feet)
(Not included)



L-Bracket (x4)
(Not included)



SEC

1.5

ALTERNATIVE SITE PREPARATION: OPTION 2 - FILLED WOOD FRAME ASSEMBLY



Cut outside frame to 123 1/2" x 153 1/2" **outside dimensions**. Lay boards flat so widest parts face up. Ensure frame is level. Square up the frame by measuring from corner to corner. Measurement A should equal Measurement B. Nail an L-Bracket on each corner of the frame with 8d nails. Place platform in the desired location. If platform does not rest level on the ground, build up low points with loose dirt or "Pea" gravel, until platform is stable.



Note: Whenever possible you should use the surfaces described on Page 7.



Note: All lumber must be rated for outdoor use.



SEC

1.6


Once all boards are level and do not wobble, pack "Pea" gravel around the outside of the frame, and slope away from frame.



SEC

1.7

Now fill the inside of the frame with "Pea" gravel. Use a leveling board to scrape off extra fill material and to level the surface.




2" x 4" x 11' Leveling Board (x1)

SEC 2 FLOOR ASSEMBLY

PLASTIC PARTS REQUIRED

LOCATED IN BOXES 1, 2, 3


Parts shown at 4% of actual size



1000466

(AGS) (x2)


Outer Floor Panel "A"



1000464

(AGT) (x2)

Outer Floor Panel "B"



(AGJ) (x8)

Inner Floor Panel

1000463

TOOLS REQUIRED



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 2



NO HARDWARE REQUIRED FOR THIS PAGE




SEC

2.1

FLOOR PANEL ASSEMBLY


Hold one (1) **Outer Floor Panel "B" (AGT)** at an angle against one (1) **Outer Floor Panel "A" (AGS)** so the tabs on Panel "B" fit underneath Panel "A", and the tabs on Panel "A" fit underneath Panel "B". Then, lay Panel "B" flat.



SEC

2.2

Hold a **Inner Floor Panel (AGJ)** at an angle against another Inner Floor Panel so the tabs on each Panel fit underneath the other Panel. Then, lay the Panel flat.



CAUTION

Sharp objects may damage your floor. If resting sharp, heavy objects on your shed floor, place a block of wood between the sharp object and floor.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 2




NO HARDWARE REQUIRED FOR THIS PAGE

SEC

2.3





Connect the Inner Floor Panels to the Outer Floor Panels following this same procedure.



SEC

2.4


Repeat Step 2.2 -2.3 to connect all the **Outer Floor Panels (AGS & AGT)** to the Inner Floor Panels. Finally, connect the last two (2) **Outer Floor Panels (AGS & AGT)** to the Inner Floor Panels.



SEC 3 TRUSS ASSEMBLY

HARDWARE REQUIRED

Hardware shown at actual size




AAK (x50)
1/4" x 1 1/2" Hex Bolt



ADJ (x50)
1/4" Cap Nut

HARDWARE BAG REQUIRED: BGV

Hardware shown at 50% of actual size



AIP (x5)
Truss Gutter Connector



AHT (x10)
Floor Bracket



METAL PARTS REQUIRED

Parts shown at 8% of actual size




71 11/16"

AFH (x10)
Truss Gutter Channel





79 1/2"

AFG (x5)
Truss Brace Channel



79 1/2"

AFQ (x10)
Wall Support Channel



20 1/8"

AFP (x10)
Truss Support Strip

TOOLS REQUIRED



7/16" Wrench (x2)



Safety Glasses




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 3




7/16" (x2)



AAK (x30)



ADJ (x30)



AIP (x5)
(Not to scale)




SEC

3.1

TRUSS ASSEMBLY

Fit two **Truss Support Strips (AFP)** together. Bolt **Truss Support Strips**, **Truss Gutter Connector (AIP)**, and two **Truss Gutter Channels (AFH)** as shown using the required hardware.



Note: Only finger tighten hardware.




WARNING

Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.

SEC

3.2

Attach **Truss Support Strips (AFP)** to the center of a **Truss Brace Channel (AFG)** (Truss Support Strips fit inside the Truss Brace Channel). Attach each end of the Truss Brace Channel to the **Truss Gutter Channels (AFH)** using the required hardware. Tighten all hardware.



WARNING

Do not overtighten the Cap Nut.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 3



7/16" (x2)



AAK (x10)




ADJ (x10)



SEC

3.3


Attach Truss Assembly to two **Wall Support Channels (AFQ)** using **1/4" x 1 1/2" Hex Bolts (AAK)** and **1/4" Cap Nuts (ADJ)**. Do not completely tighten the Cap Nut until after Truss is secured to the Wall.



AFQ



Note: Only finger tighten hardware.



WARNING

Do not overtighten the Cap Nut.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 3



7/16" (x2)



AAK (x10)



ADJ (x10)




AHT (x10)
(Not to scale)



SEC

3.4

Attach one **Floor Bracket (AHT)** to the bottom of each Wall/Shelf Support Channel using the required hardware. Tighten all hardware. Repeat this section for all Trusses. You need only do this step if you plan to anchor your Shed. See the "Anchoring the Shed" step at the end of this Owner's Manual.



SEC 4 WALL PANEL INSTALLATION

HARDWARE REQUIRED

HARDWARE BAG REQUIRED: BMX

Hardware shown at actual size



ADZ (x116)
1/4" x 5/8" Pan-Head Screw




ADC (x1)
#2 Phillips Bit

METAL PARTS REQUIRED

METAL PARTS KIT REQUIRED: BUA

Part shown at 8% of actual size




AFR (x4)
Corner Channel




PLASTIC PARTS REQUIRED

BOXES: 2, 3

Parts shown at 4% of actual size




AHD (x14)
Wall Panel



AHH (x2)
Window Wall Panel

TOOLS REQUIRED



#2 Phillips Screwdriver



3/8" Wrench



ADC (x1)
#2 Phillips Bit (Included)



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 4



NO HARDWARE REQUIRED FOR THIS PAGE




2 PEOPLE REQUIRED FOR ASSEMBLY

SEC

WALL ASSEMBLY

4.1


Lock a **Wall Panel (AHD)** into the front, right corner of the Floor by inserting the tabs at the bottom of the Wall Panel into the slots on the Floor. After inserting the tabs, slide the Wall Panel to the right as far as it will go.



SEC

4.2


Lock a second **Wall Panel (AHD)** adjacent to the front along the right edge of the Floor by inserting the tabs at the bottom of the Wall Panel into the slots on the Floor. **The Window Wall Panel (AHH) may be inserted into any side Wall Panel position.** After inserting the tabs, slide the Wall Panel towards the front, right corner.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 4




ADZ (x36)



SEC

4.3


Align the holes in a **Corner Channel (AFR)** with the holes in two corner Wall Panels and secure the Corner Channel to the Wall Panels with twelve (12) **1/4" x 5/8" Phillips Pan-Head Screws (ADZ)**.



SEC

4.4

Insert one (1) **Window Wall Panel (AHH)** and three (3) **Wall Panels (AHD)** along the right edge of the Floor. The **Window Wall Panel (AHH)** may be inserted into any side **Wall Panel** position. Secure the Panels to one another using twenty-four (24) **1/4" x 5/8" Pan-Head Screws (ADZ)**.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x66)


SEC 4



SEC

4.5


Insert four (4) **Wall Panels (AHD)** along the rear edge of the Floor. Secure the Panels and one (1) **Corner Wall Channel (AFR)** using twenty-four (24) **1/4" x 5/8" Pan-Head Screws (ADZ)**.



SEC

4.6


Insert three (3) **Wall Panels (AHD)** and one (1) **Window Wall Panel (AHH)** along the left edge of the Floor. **The Window Wall Panel (AHH)** may be inserted into any side Wall Panel position. Secure the Panels to one another using one (1) **Corner Wall Channel (AFR)** and thirty-six (36) **1/4" x 5/8" Pan-Head Screws (ADZ)**.



Note: A second adult should apply pressure to the opposite side of the wall for easy insertion of screws.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x12)


SEC 4



SEC

4.7

Lock the last **Wall Panel (AHD)** into the front, left corner of the Floor by inserting the tabs at the bottom of the Wall Panel into the slots on the Floor. After inserting the tabs, slide the Wall Panel to the left as far as it will go. Secure the Panel to the Wall using one (1) **Corner Wall Channel (AFR)** and twelve (12) **1/4" x 5/8" Pan-Head Screws (ADZ)**.




! Note: A second adult should apply pressure to the opposite side of the wall for easy insertion of screws.

SEC 5 TRUSS & WALL/SHELF SUPPORT CHANNEL INSTALLATION


HARDWARE REQUIRED

HARDWARE BAG REQUIRED: CJW

Hardware shown at actual size (*Unless noted otherwise)



ADZ (x128)
1/4" x 5/8" Pan-Head Screw
(Not all screws are used)



AAK (x18)
1/4" x 1 1/2" Pan-Head Screw



ADJ (x18)
1/4" Cap Nut




***ANT** (x6)
Floor Bracket


METAL PARTS REQUIRED

METAL PARTS KITS REQUIRED: BUA, BNK


Parts illustrated at 8% of the actual size



AFQ (x6)
Wall/Shelf Support Channel




AFJ (x2)
Long Wall/Shelf Support Channel Extension




AFN (x4)
Short Wall/Shelf Support Channel Extension

Part not illustrated at any specific size



Truss Assembly (x5)

TOOLS REQUIRED




Phillips Screwdriver



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




SEC 5

ADZ (x76)

**SEC****5.1**

TRUSS INSTALLATION

Starting at the back of the shed, secure a Truss Assembly to the center of the Wall Panels on the left and right Walls with sixteen (16) 1/4" x 5/8" Pan-Head Screws (ADZ). Repeat this step for each Truss Assembly. The Window Wall Panels only use six (6) 1/4" x 5/8" Pan-Head Screws (ADZ) each.




Do not insert any 1/4" x 5/8" Pan-Head Screws (ADZ) through these two holes in the two Window Wall Panels. These two holes are used later on in the Window Assembly and Installation Section.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

7/16" (x2)



AAK (x12)



ADJ (x12)

SEC 5



SEC

5.2


SHORT WALL SUPPORT CHANNEL EXTENSION ASSEMBLY

Slide a **Short Wall Support Channel Extension (AFN)** into the top of a **Wall Support Channel (AFQ)** and secure with two (2) 1/4" x 1 1/2" Hex Bolts (AAK) and two (2) 1/4" Cap Nuts (ADJ). Repeat this step for the remaining three Short Wall Support Extensions.



AFN

Use these two holes




SEC


5.3

LONG WALL SUPPORT CHANNEL EXTENSION ASSEMBLY

Slide a **Long Wall Support Channel Extension (AFJ)** into the top of a **Wall Support Channel (AFQ)** and secure with two (2) 1/4" x 1 1/2" Hex Bolts (AAK) and two (2) 1/4" Cap Nuts (ADJ). Repeat this step for the remaining Long Wall Support Extensions.



AFJ




WARNING


Do not overtighten the Cap Nut.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 5**7/16" (x2)****AAK (x6)****ADJ (x6)****AHT (x6)**
(Not to scale)**SEC****5.4**


Attach one **Floor Bracket (AHT)** to the bottom of each Wall Support Channel. Tighten all hardware. Repeat this section for all Trusses. You need only do this step if you plan to anchor your Shed. See the "Anchoring the Shed" step at the end of your Owner's Manual.

**WARNING**

Do not overtighten the Cap Nut.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x16)

SEC 5




SEC

5.5

FRONT WALL SUPPORT CHANNEL INSTALLATION

Using the middle set of eight pre-made holes in the Left, Front Wall Panel, secure a Short Wall Support Channel Assembly to the Left, Front Wall Panel using eight (8) 1/4" x 5/8" Pan-Head Screws (ADZ). Repeat this step for the Right, Front Wall Panel.



Middle set of eight pre-made holes



Interior View




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 5**ADZ (x32)****SEC****5.6**

REAR WALL SUPPORT CHANNEL INSTALLATION


Using the middle set of eight pre-made holes in the Right, Rear Wall Panel, secure a Short Wall Support Channel Assembly to the Right, Rear Wall Panel using eight (8) $\frac{1}{4}$ " x $\frac{5}{8}$ " Pan-Head Screws (ADZ). Repeat this step for the Left, Rear Wall Panel. Using the middle set of eight pre-made holes in the two Center, Rear Wall Panels, secure Long Wall Support Channel Assemblies to the Center, Rear Wall Panels using eight (8) $\frac{1}{4}$ " x $\frac{5}{8}$ " Pan-Head Screws (ADZ) for each Wall Support Channel Assembly.

**Interior View****Right, Rear Wall Panel**

SEC 6 LEFT DOOR ASSEMBLY

HARDWARE REQUIRED

Hardware shown at of actual size



ADZ (x9)
1/4" x 5/8" Pan-Head Screw



ADW (x3)
#10 x 3/4" Phillips
Pan-Head Screw



ACH (x2)
1/4" x 1 1/2" Carriage Bolt



ADJ (x2)
1/4" Cap Nut



AEE (x3)
#10 x 1/2" Flat Washer

Hardware shown at 15% of actual size



AHZ (x1)
Left Door Handle

Hardware shown at 25% of actual size



AHM (x2)
Deadbolt Latch




AIB (x1)
Left Door Strike Plate




AIA (x1)
Left Door Lock Bracket

METAL PARTS REQUIRED

Parts shown at 8% of actual size



AFC (x1)
Door End Channel




AFB (x3)
Door Brace

PLASTIC PARTS REQUIRED


LOCATED IN BOX 4

Part shown at 4% of actual size



1001790
AGO (x1) Left Door

TOOLS REQUIRED



Phillips Screwdriver



7/16" Wrench



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 6



AHM (x2)




SEC

6.1

LEFT DOOR ASSEMBLY

Rest **Left Door (AGO)** with front side down. Position **Deadbolt Latches (AHM)** in slots at top and bottom of Door then slide **Door End Channel (AFC)** onto the Door.



! Note: The Door End Channel fits onto Door with the flat side up (facing the Deadbolt Latches).



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x9)



AIB (x1)


SEC 6



SEC

6.2


Attach three **Door Braces (AFB)** to the back of the Door with **1/4" x 5/8" Phillips Pan-Head Screws (ADZ)**.



SEC

6.3


Slip the **Left Door Strike Plate (AIB)** over the Left Door and align the holes.



Note: You may need to nudge the Door End Channel to make these holes line up with the gap in the Door.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



7/16"



ACH (x2)



ADJ (x2)



AIA (x1)



ADW (x3)



AEE (x3)



AHZ (x1)




SEC 6

SEC

6.4


Attach the **Left Door Lock Bracket (AIA)** to the Strike Plate with two (2) **1/4" x 1 1/2" Carriage Bolts (ACH)** and two (2) **1/4" Cap Nuts (ADJ)**.



SEC

6.5

Attach the **Left Door Handle (AHZ)** using three (3) **#10 x 1/2" Flat Washers (AEE)** and three (3) **#10 x 3/4" Pan-Head Screws (ADW)**.



SEC 7 RIGHT DOOR ASSEMBLY

HARDWARE REQUIRED

HARDWARE BAG REQUIRED: BKC

Hardware shown at of actual size



ADZ (x9)
1/4" x 5/8" Pan-Head Screw




ADW (x4)
#10 x 3/4" Pan-Head Screw



AEE (x3)
#10 x 1/2" Flat Washer



ADB (x2)
3/8" x 1/2" Steel Spacer



AHY (x1)
Latch Spring



ACI (x2)
1/4" x 2" Carriage Bolt



AAB (x2)
1/4" Centerlock Nut



AEB (x2)
1/4" Flat Washer


Hardware shown at 25% of actual size



AIO (x1)
Thumb Lever



AHV (x1)
Door Latch




AIL (x1)
Right Door Lock Bracket



AHX (x1)
Latch Cover Plate

Hardware shown at 15% of actual size



AIK (x1)
Right Door Handle

Hardware shown at 50% of actual size




AHW (x1)
Latch Block


METAL PARTS REQUIRED

METAL PARTS KIT REQUIRED: BUA

Parts shown at 8% of actual size



AFC (x1)
Door End Channel




AFB (x3)
Door Brace

PLASTIC PARTS REQUIRED


LOCATED IN BOX 4

Part shown at 4% of actual size



AGZ (x1)
Right Door

TOOLS REQUIRED



Phillips Screwdriver



7/16" Wrench



Pliers



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 7



NO HARDWARE REQUIRED FOR THIS PAGE




SEC

7.1


RIGHT DOOR ASSEMBLY

Rest **Right Door (AGZ)** with front side down, then slide **Door End Channel (AFC)** onto the Door.






TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (9)



AIO (x1)



AIK (x1)


SEC 7



SEC

7.2


Attach three **Door Braces (AFB)** to the back of the Door with nine (9) **1/4" x 5/8" Phillips Pan-Head Screws (ADZ)**.



SEC

7.3

Fit the **Thumb Lever (AIO)** knobs into the grooves in the **Right Door Handle (AIK)**.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AEE (x3)



ADW (x3)


SEC 7



SEC

7.4


Rotate the Thumb Lever into the Handle. Slide forward until the Knobs fit into the holes in the Handle.



SEC


7.5

Attach the Handle and Thumb Lever to the Door using the required hardware.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



7/16"



AHX (x1)
(Not to scale)



AHV (x1)
(Not to scale)




AAB (x2)



AEB (x2)



ACI (x2)



AIL (x1)
(Not to scale)



ADB (x2)


SEC
7



SEC


7.6

Connect the Right Door Handle to the Right Door using the hardware shown. Tighten all hardware.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHY (x1)



AHW (x1)
(Not to scale)



ADW (x1)


SEC 7



SEC

7.7

Line up the hole in the **Latch Block (AHW)** with the hole in the **Thumb Lever (AIO)**, and secure in place with a **#10 x 3/4" Phillips Pan-Head Screw (ADW)**.




Note: The lip of the Latch Block (AHW) fits under the Thumb Lever (AIO).

SEC

7.8

Attach **Latch Spring (AHY)** to handle assembly. Set the Door aside.



Note: The Latch Block and Thumb Lever are not shown in this illustration in order to better show the correct placement of the Latch Spring.



Note: Use pliers to pull spring down and hook into bottom hole.



WARNING

While performing this step, each person should use protective eye glasses to help prevent serious eye injury.

SEC 8 GABLE ASSEMBLY

HARDWARE REQUIRED

Hardware shown at actual size



AEE (x10)
#10 x 1/2" Flat Washer




ADW (x10)
#10 x 3/4" Pan-Head Screw




ADZ (x8)
1/4" x 5/8" Pan-Head Screw

Parts shown at 15% of actual size



AGP (x2)
Louvered Vent



AIQ (x2)
Vent Screen

PLASTIC PARTS REQUIRED

LOCATED IN BOX 1

Parts shown at 4% of actual size




AGH (x2)
Gable Half 1



AGI (x2)
Gable Half 2

TOOLS REQUIRED



Phillips Screwdriver



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x8)

SEC 8




SEC

8.1

GABLE ASSEMBLY


Set the edge of **Gable Half 2 (AGI)** over the edge of **Gable Half 1 (AGH)** as shown.



SEC


8.2

Secure the two Gable Halves together using four (4) 1/4" x 5/8" Pan-Head Screws (ADZ).





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AEE (x10)



ADW (x10)


SEC 8



SEC

8.3

Attach the **Louvered Vent (AGP)** and **Vent Screen (AIQ)** to the Gable Assembly using five (5) #10 x 1/2" Flat Washers (AEE) and five (5) #10 x 3/4" Phillips Pan-Head Screws (ADW). Set the Gable Assembly aside until later. Repeat this section for the second Gable.



SEC 9 DOMED SKYLIGHT ASSEMBLY

HARDWARE REQUIRED

Hardware shown at actual size (*Unless noted otherwise)



ACR (x24)
#10 x 5/8" Carriage Bolt



ADK (24)
#10 Cap Nut




AEE (24)
#10 x 1/2" Flat Washer



***AHI** (x2)
Butyl Tape

PLASTIC PARTS REQUIRED

Part shown at 4% of actual size




1015533

AHB (x2)
Roof Panel for Domed Skylight


LOCATED IN BOXES 2, 3

Part shown at 8% of actual size



AGB (x2)
Domed Skylight

TOOLS REQUIRED



Phillips Screwdriver




3/8" Wrench



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHI (x2)
(Not to scale)

SEC 9




SEC


9.1

DOMED SKYLIGHT ASSEMBLY

Use a plain screwdriver to gently remove any excess plastic from the twelve holes in the **Roof Panel for Domed Skylight (AHB)**. It's important that the hole stay square; try not to round the corners of the edges of the holes. Stick the end of the **Butyl Tape (AHI)** over the groove and top, left hole of the Roof Panel for Domed Skylight as indicated below. Move to the right and over the groove covering all the holes along the top of the opening. Once the top, right corner and hole are covered, cut the Butyl Tape. Run your finger along the paper backing pressing down slightly to remove any gaps or bubbles between the Butyl Tape and the groove. Remove the paper backing from the piece of Butyl Tape you just applied. Overlap the end of the roll of Butyl Tape with the end you just cut and apply the Butyl Tape over the holes along the groove on the right of the opening. Continue applying the Butyl Tape in this fashion until all holes have been covered and the ends overlap.



Note: Use a screwdriver to remove any excess plastic from all holes in Panel.




Note: Butyl Tape must cover all twelve holes.


SEC

9.2

Remove the protective plastic film from **both** sides of the **Domed Skylight (AGB)**. Carefully align the holes in the Domed Skylight with those in the Butyl Tape. Set the Domed Skylight over the opening in the Roof Panel for Domed Skylight. Press down and verify there are no gaps or bubbles between the Butyl Tape and the Domed Skylight.



AGB (x2)




Exterior View



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



3/8"



ACR (x24)



ADK (x24)



AEE (x24)



SEC 9



SEC

9.3

Insert one (1) #10 x 5/8" Carriage Bolt (ACR) through each hole in the Domed Skylight. Press the Bolt through the Butyl Tape and through the Roof Panel for Domed Skylight.




Exterior View


SEC

9.4

Secure the Domed Skylight to the Roof Panel with one (1) #10 Flat Washer (AEE) and one (1) #10 Cap Nut (ADK) for each Carriage Bolt. Set Skylight/Panel Assembly aside.



Interior View



WARNING


Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.

SEC 10 DOOR & ENTRY GABLE INSTALLATION

HARDWARE REQUIRED

HARDWARE BAG REQUIRED: BKD

Hardware shown at actual size (*Unless noted otherwise)



ADZ (x24)
1/4" x 5/8" Pan-Head Screw



ACH (x4)
1/4" x 1 1/2" Carriage Bolt



***AHL (x1)**
Dead Bolt Strike Plate




***AHN (x2)**
Floor Bracket



ADX (x2)
#10 x 1/2" Pan-Head Screw



ADJ (x8)
1/4" Cap Nut



ACA (x4)
1/4" x 1/2" Carriage Bolt



AEB (x4)
1/4" Flat Washer

METAL PARTS REQUIRED

DOOR HINGE & METAL PARTS KIT REQUIRED: BTI, BUA

Parts shown at 8% of actual size



AFI (x1) Left Hinge Assembly



AFK (x1) Right Hinge Assembly




AFD (x1)
Door Header



PLASTIC PARTS REQUIRED


FROM STEPS 6, 7, 8

Parts shown at 4% of actual size




1000472
Front Gable Assembly

Rear View **1000470**



1001790
Left Door Assembly


Rear View



Right Door Assembly

1001787
Rear View

TOOLS REQUIRED



Phillips Screwdriver



Pliers



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


**SEC 10**

2 ADULTS REQUIRED FOR THESE STEPS



SEC**10.1**

FRONT GABLE INSTALLATION

Set the Front Gable Assembly in front of the two short Wall Support Channels and on the two front Wall Panels as shown.

**SEC****10.2**

Align the holes in the sides of the Front Gable Assembly with those in the tops of the front Wall Panels and secure with eight (8) 1/4" x 5/8" Pan Head Screws (ADZ) at the locations indicated. Also, secure the Entry Gable Assembly to the Wall Support Channel Extensions using two (2) 1/4" x 5/8" Pan Head Screws (ADZ).






TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 10

AHN (x2)
(Not to scale)



ACA (x4)




ADJ (x4)


**SEC****10.3**

DOOR FRAME ASSEMBLY & INSTALLATION


Insert a 1/4" x 1/2" Carriage Bolt (ACA) through the top hole of the **Right Door Hinge (AFK)** as shown, and secure with a 1/4" Cap Nut (ADJ). Only hand tighten the Cap Nut for now. Repeat this step for the **Left Door Hinge (AFI)**.



Right Door Hinge




Left Door Hinge




Note: To help you distinguish between the Left and Right Hinge Assemblies, the Trim Brackets on the Right Hinge Assembly (AFK) start about five inches in from the ends.

SEC**10.4**

Attach a **Floor Bracket (AHN)** to the bottom of the **Right Door Hinge** using a 1/4" x 1/2" Carriage Bolt (ACA) and a 1/4" Cap Nut (ADJ). Only hand tighten the Cap Nut for now. Repeat this step for the **Left Door Hinge (AFI)**.




Right Door Hinge



Left Door Hinge



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x5)

SEC 10





SEC

10.5



DOOR FRAME INSTALLATION

Slide the Right Door Hinge Assembly over the right, front Wall Panel and secure the Hinge Assembly to the Wall Panel using five (5) 1/4" x 5/8" Pan-Head Screws (ADZ).





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x5)




SEC 10



SEC


10.6

Slide the Left Door Hinge Assembly over the left, front Wall Panel and secure the Hinge Assembly to the Wall Panel using five (5) 1/4" x 5/8" Pan-Head Screws (ADZ).





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE






SEC 10



SEC


10.7

Carefully remove the 1/4" Cap Nut from the top of the Left Door Hinge Assembly. Place the **Door Header (AFD)** at the top of the Door Hinge Assembly so 1/4" x 1/2" Carriage Bolt goes through the elongated hole on the Door Header as shown. Carefully replace the 1/4" Cap Nut. **Repeat this step for the Right Door Hinge Assembly.** Finally, secure the Door Header to the Front Gable using four (4) 1/4" x 5/8" Pan-Head Screws (**ADZ**) at the locations shown.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



NO HARDWARE REQUIRED FOR THIS PAGE

SEC 10




SEC

10.8


DOOR INSTALLATION

Slide the edge of the Left Door Assembly down into the end of the Left Hinge Assembly as shown.







TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


SEC 10**AEB (x4)****ADJ (x4)****ACH (x4)****SEC****10.9**

Align the notch in the Left Door Assembly with the two holes in the end of the Left Hinge Assembly, and insert two (2) $\frac{1}{4}$ " x $1\frac{1}{2}$ " Carriage Bolts (ACH). Secure the Door to the Hinge using two (2) $\frac{1}{4}$ " Flat Washers (AEB) and two (2) $\frac{1}{4}$ " Cap Nuts (ADJ). Repeat these steps for the Right Door Assembly.

**Back of Door**



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHL (x1)
(Not to scale)



ADX (x2)


SEC 10



SEC

10.10

Secure the **Deadbolt Strike Plate (AHL)** to the Floor using two (2) **#10 x 1/2" Pan-Head Screws (ADX)**.



SEC 11 TRIM INSTALLATION


HARDWARE REQUIRED

HARDWARE BAG REQUIRED: BND

Hardware shown at actual size (*Unless indicated otherwise)



ADX (56)
#10 x 1/2" Pan-Head Screw




ACK (4)
#8 x 1" Pan-Head Screw



***AHR (x2)**
Door Trim Clip



***AHQ (x4)**
Door Trim Bracket




***AGA (x24)**
Corner Trim Bracket


PLASTIC PARTS REQUIRED

LOCATED IN BOX 4


Parts shown at 4% of actual size



AGC (x1) Top Door Trim




AGD (x2) Side Door Trim



AQX (x4) Corner Trim

TOOLS REQUIRED



Phillips Screwdriver



Safety Glasses





7/16" Wrench (x2)



Pliers



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AHQ (x4)
(Not to scale)

SEC 11




SEC

11.1

DOOR TRIM INSTALLATION


Slide **Side Door Trim (AGD)** into place onto Door Hinge Brackets.



SEC

11.2

Attach four (4) **Door Trim Brackets (AHQ)** above the Door frame at the locations shown.



Note: Look for screw hole locator marks above the Door frame.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 11



AHR (x2)
(Not to scale)



SEC

11.3

Slide **Door Trim Clips (AHR)** into the top of the Side Door Trim (Fig. 1), on each side of the Door. Slide the **Top Door Trim (AGC)** into place, and secure with the Door Trim Clips (Fig. 2).




Fig. 1





Fig. 2




Note: You may need to slightly bend the tab outward with pliers.




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADX (x48)



ACK (x4)



AGA (x24)
(Not to scale)

SEC 11




SEC

11.4

CORNER TRIM INSTALLATION

Snap six (6) **Black Trim Brackets (AGA)** to a corner of the Shed. Fasten each Bracket with two (2) **#10 x 1/2" Screws (ADX)**. There are no pilot holes in the Shed Wall; the Screws are inserted directly into the plastic.



Note: The tab on the Trim Brackets fit into the six screw indentations along each corner of the Shed.






WARNING

Use extreme caution when standing on ladders to perform assembly steps. Follow all warnings and cautions on the ladder. Failure to follow all of these instructions and warnings could lead to serious personal injury or property damage.

SEC

11.5

Slide **Corner Trim Piece (AQX)** onto the Brackets. Align the Trim Piece with the top of the Wall Panel and fasten with one (1) **#8 x 1" Pan-Head Screw (ACK)**. Insert the Screw on the side of the Shed so that it will be hidden by the Roof overhang.




Note: Ensure the Corner Trim Piece is even with the front edge of the Wall Panel before securing with Screw.

SEC 12 ROOF & REAR GABLE INSTALLATION

HARDWARE REQUIRED

Hardware shown at actual size (*Unless otherwise noted)




ADZ (x220)
1/4" x 5/8" Pan-Head Screw
(Not all screws will be used)



***AJA (x20)**
Foam Cube



ADK (x1)
#10 Cap Nut



AED (x16) #10 x 1"
Fender Washer



ACJ (x16)
#10 x 5/8" Pan-Head Screw



ADX (x4)
#10 x 1/2" Pan-Head Screw




ACF (x1)
#10 x 5/16" Pan-Head Screw

METAL PARTS REQUIRED

Parts shown at 8% of actual size



AFL (x24)
Roof Support Strip



AFF (x2)
Gable Truss Brace

LOCATED IN BOXES 1, 2, 3

PLASTIC PARTS REQUIRED

Parts shown at 4% of actual size




AGU (x2) Outer Roof Panel "A"




AGV (x2) Outer Roof Panel "B"



AFY (x4)
Center Roof Cap




AGQ (x6)
Inner Roof Panel



AHB (x2)
Inner Roof Panel for Domed Skylight




***AHA (x2)**
Roof Cap Cover



AGE (x2) End Roof Cap

TOOLS REQUIRED



Phillips Screwdriver



7/16" Wrench




Flashlight



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x24)



SEC 12



SEC

12.1

Install two **Outer Roof Panels "A" & "B" (AGU & AGV)** at the front of the shed as shown. The top of the Wall Panel fits into the groove near the bottom edge of the Panel. Align the holes in the Wall Panel, Entry Gable, and Truss Assembly with those in the Outer Roof Panel. Secure the Outer Roof Panels to the Entry Gable, Wall Panels, and Truss Assembly using twenty-four (24) **1/4" x 5/8" Pan-Head Screws (ADZ)**.




The top of the Wall Panel fits into this groove



Interior Upward View



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 12**ADZ (x24)****AFL (x6)****SEC****12.2**

Install two **Roof Panels (AGQ or AHB)** next to the Outer Roof Panels as shown. **The Inner Roof Panel for Domed Skylight (AHB) may be inserted into any Inner Roof Panel position.** Insert three (3) **Roof Support Strips (AFL)** into the grooves of each Roof Panel (AGQ & AHB) to provide support for the Panels. Secure both Panels to the Truss Assemblies using twenty-four (24) **1/4" x 5/8" Pan-Head Screws (ADZ)**.

**Interior Upward View**



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x72)



AFL (x18)


SEC 12



SEC

12.3

Continue installing the next six Roof Panels (**Inner Roof Panel for Domed Skylight** and **Inner Roof Panels**) and **Roof Support Strips** next to the previous two Roof Panels as shown. The **Inner Roof Panel for Domed Skylight** may be inserted into any **Inner Roof Panel** position. Secure the Panels to the Truss Assemblies using seventy-two (72) 1/4" x 5/8" Pan-Head Screws (ADZ).





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x22)



SEC 12



SEC

12.4

Install the Rear Gable Assembly to the tops of the rear Wall Panels using sixteen (16) 1/4" x 5/8" Pan-Head Screws (ADZ). Also, secure the Rear Gable Assembly to the Wall Support Channel Extensions using six (6) 1/4" x 5/8" Pan-Head Screws (ADZ).





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x24)


SEC 12



SEC

12.5


Install the last two **Outer Roof Panels "A" & "B" (AGU & AGV)** at the rear of the shed as shown. Secure the Outer Roof Panels to the Rear Gable and Truss Assembly using twenty-four (24) **1/4" x 5/8" Pan-Head Screws (ADZ)**.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


SEC 12



ADZ (x28)



ACJ (x16)



AED (x16)





SEC

12.6


Starting at the front of the shed, install the two (2) **End Roof Caps (AGE)** and four (4) **Center Roof Caps (AFY)** to the Roof. Connect the Roof Caps to the Trusses and Gables using **1/4" x 5/8" Pan-Head Screws (ADZ)** and to the Roof Panels using **#10 x 5/8" Pan-Head Screws (ACJ)** and **#10 x 1" Fender Washers (AED)**.



Only use a hand screwdriver on this step




Attach Roof Caps to both sides of Trusses using 1/4" x 5/8" Pan-Head Screws (ADZ).



Attach Roof Caps Roof Panels using #10 x 5/8" Pan-Head Screws (ACJ) and #10 x 1" Fender Washers (AED).



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x4)



SEC 12



SEC

12.7

Connect a **Roof Cap Cover (AHA)** to the Front of the Shed as shown using the required hardware. Repeat this step for the rear of the shed.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



7/16"



ADX (x4)



ADK (x1)



ACF (x1)



SEC 12




SEC

12.8

Connect a **Gable Truss Brace (AFF)** between the front Truss Assembly and Entry Gable and the rear Truss and Rear Gable Assemblies using two (2) **#10 x 1/2" Pan-Head Screws (ADX)** each. Secure the Gable Truss Brace into the Door Header Channel (on Entry Gable) using one (1) **#10 x 5/16" Pan-Head Screw (ACF)** and one (1) **#10 Cap Nut (ADK)**.




Remove the Hex Bolts and Cap Nuts from the Truss and use them to connect the Gable Truss Brace to the Truss.



There are no pilot holes in the Gable to receive the Screws (ADX). Insert them directly into the plastic.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADZ (x20)



AJA (x20)
(Not all are used)


SEC 12



SEC

12.9


Along the outside of the shed, underneath the eaves, fasten the Truss Assemblies to the Roof Panels using two (2) 1/4" x 5/8" Pan-Head Screws (ADZ) per Truss Assembly.



SEC

12.10

Insert two Foam Cubes (AJA) at each truss location.




AJA

SEC 13 WINDOW ASSEMBLY & INSTALLATION

HARDWARE REQUIRED

HARDWARE BAG REQUIRED: BGU (x2)

Hardware shown at actual size



ADZ (x8)
1/4" x 5/8" Pan-Head Screw



ADW (x8)
#10 x 3/4" Pan-Head Screw



ADX (x44)
#10 x 1/2" Pan-Head Screw



AEE (x4)
#10 x 1/2" Flat Washer



ACF (x4)
#10 x 5/16" Pan-Head Screw



ACB (x8)
#10 x 1 1/4" Pan-Head Screw



ACD (x4)
#10 x 3/8" Flat-Head Screw



ADK (x4)
#10 Cap Nut


Hardware shown at 25% of actual size



AIE (x4)
Mounted Window Stay



AIN (x4)
Sliding Window Stay




AIV (x4)
Window Stay Bracket



AIR (x8)
Window Hinge Tube

Hardware shown at 50% of actual size



AIU (x8)
Window Latch Bearing




AIT (x8)
Window Latch


PLASTIC PARTS REQUIRED

LOCATED IN BOXES 2, 3

Parts shown at 8% of actual size




AHG (x4)
Window Frame



AHF (x4)
Window

TOOLS REQUIRED




Phillips Screwdriver



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIR (x4)
(Not to scale)


SEC 13



SEC


13.1

Slide **Window Hinge Tubes (AIR)** into the upper and lower hinge holes and fit a **Window Frame (AHG)** over the Hinge Tubes.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ADX (x20)

SEC 13





SEC

13.2

Place a **Window (AHF)** onto the Window Frame. Fasten the Window to the Frame with **#10 x 1/2" Pan Head Screws (ADX)** in the locations shown.



Note: Remove plastic film from both sides of window before installing.



Note: Insert Screws into the holes with circles.



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIV (x2)
(Not to scale)



AIE (x2)
(Not to scale)



ADW (x4)



ADZ (x4)




SEC 13

SEC

13.3


Attach **Window Stay Brackets (AIV)** to the inside of the **Window Wall Panel (AHH)**.



SEC


13.4

Attach a **Mounted Window Stay (AIE)** to the bottom of the **Window Frame**.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AEE (x2)



ADX (x2)



AIN (x2)
(Not to scale)



ACF (x2)




SEC 13



SEC

13.5




Fit a **Sliding Window Stay (AIN)** into the **Mounted Window Stay**. To add rigidity to the nub of the Sliding Window Stays, insert **#10 x 1/2" Pan-Head Screws (ADX)** as shown.



SEC



13.6

Attach a **Sliding Window Stay (AIN)** to the **Window Stay Bracket (AIV)** using the required hardware.






TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



AIT (x4)
(Not to scale)



AIU (x4)
(Not to scale)



ACB (x4)

SEC 13







SEC

13.7

Fit a **Window Latch Bearing (AIU)** into a **Window Latch (AIT)**. Attach the Window Latch to the upper latch location with a #10 x 1 1/4" Pan-Head Screw (**ACB**). Repeat for other Window Latches.




Note: Ensure notch in Window Latch Bearing fits over the plastic ridge in the Window Frame.





TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



ACD (x4)



ADK (x4)

SEC 13




SEC

13.8

WINDOW ASSEMBLY & INSTALLATION

From the outside, push two (2) **#10 x 3/8" Flat-Head Screws (ACD)** through the holes in the window divider in the Window Wall Panel and the Wall/Shelf Support Channel. Secure with two (2) **#10 Cap Nuts (ADK)**. Repeat this section for all Windows.



Note: You will need to push the Screws (ACD) through the thin layer of plastic covering the holes. The Cap Nuts (ADK) go on the inside.




WARNING

Do not overtighten the Cap Nut. If the end of the Bolt breaks through the plastic cap, call our Customer Service Department. Exposed threads on the end of the Bolt may cause serious injuries.


SEC 14 PEGBOARD STRIP INSTALLATION

HARDWARE REQUIRED

Hardware shown at actual size




ADW (x10)
#10" x 3/4" Pan-Head Screw



AIF (x1)
2" Double-Arm Hook


Hardware shown at 50% of actual size




AIG (x1)
4" Double-Arm Hook



AIJ (x2)
Toolholder




AIH (x3)
J-Hook



AII (x3)
L-Hook

PLASTIC PARTS REQUIRED


Parts shown at 15% of actual size



AFU (x2)
Pegboard Strip

LOCATED IN BOX 1 SHED PARTS BOX: BTH

TOOLS REQUIRED



Phillips Screwdriver



Safety Glasses




Level



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 14



ADW (x10)




SEC

14.1

PEGBOARD STRIP INSTALLATION

Using a level, position the **Pegboard Strip (AFU)** in any desired location along a Wall Panel wall. Screw the Pegboard Strip to the Wall using five (5) **#10 x 3/4" Phillips Pan-Head Screws (ADW)**. See Note. Repeat this step for second Pegboard Strip.

! Note: The Pegboard Strip is screwed directly into the plastic. Line up the Strip anywhere on Wall so holes are over plastic (and not over a groove in the Wall).



! Note: Ensure the Pegboard Strip is level before inserting Screws.

SEC

14.2

Insert **Hooks (AIF, AIG, AIH, AII, and AIJ)**.

SEC 15 SHELF ASSEMBLY

HARDWARE REQUIRED

Hardware shown at actual size



ADZ (x70)
#10 x 1/2" Pan-Head Screw
(Not all are used)

HARDWARE BAG REQUIRED: BHH (x5), BMY (x2)

Parts shown at 15% of actual size



AIY (x10)
10" Shelf Bracket

Hardware shown at actual size



ADX (x8)
#10 x 1/2" Pan-Head Screw
(Not all are used)



AEE (x8)
#10 x 1/2" Flat Washer
(Not all are used)

METAL PARTS REQUIRED

LOCATED IN BOX 1 SHED PARTS BOX: BTH

Parts shown at 15% of actual size



AIZ (x4)
14" Shelf Bracket

PLASTIC PARTS REQUIRED

LOCATED IN BOX 1

Parts shown at 4% of actual size



1002314


AFS (x5)
10" x 30" Shelf



1002315

AFT (x2)
14" x 30" Shelf

TOOLS REQUIRED



Phillips Screwdriver



Safety Glasses




TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



SEC 15**ADZ (x20)****ADX (x8)****AEE (x8)****SEC****15.1**

10" & 14" SHELF ASSEMBLY

Insert the 10" Shelf Support Brackets (AIY) into the slots of adjacent Wall/Shelf Support Channels. Insert the Shelf Support Brackets at an angle, and then set them straight.

**SEC****15.2**

Place the 10" x 30" (AFS) on the Shelf Support Brackets and fasten them with 1/4" x 5/8" Pan-Head Screws (ADZ). Repeat this section for the 14" x 30" Shelves with #10 x 1/2" Pan-Head Screws (ADX) and #10 Flat Washers (AEE).



WARNING

The total weight placed on a 10" x 30" Shelf cannot exceed 30 pounds (14kg.) per Wall Panel.

SEC 16 FINAL STEPS

HARDWARE REQUIRED


HARDWARE BAG REQUIRED: BTM

Hardware shown at actual size



ADZ (x4)
1/4" x 5/8" Pan-Head Screws

TOOLS REQUIRED



Phillips Screwdriver



Hammer Drill



3/16" Masonry Bit



Safety Glasses



TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 16



ADZ (x4)




SEC

16.1


DOOR SPACING ADJUSTMENT

You may need to move the tops and/or bottoms of the Doors to eliminate uneven gaps between the Doors. Loosen the Carriage Bolts at the four corners of the Door Frame. Loosen all screws in the left and right Door Hinges by a half a turn. Move Doors until gaps are even. Re-tighten all hardware. After all hardware has been retightened, secure the hinges to the Floor using four (4) 1/4" x 5/8" Pan-Head Screws (ADZ).


Loosen the Screws in both Hinges before adjusting Doors.



Loosen these Carriage Bolts before adjusting Doors.



Right Door Hinge



Left Door Hinge


SEC

16.2

ANCHORING THE SHED

If you plan on anchoring your shed to your platform, ensure your shed is in the position you would like it to be on your Platform. While another person holds the Shed in place, use a 3/16" masonry bit (for concrete platforms) or a 3/16" drill bit (for wooden platforms) to drill through the hole in each L-Bracket at the bottom of each Wall Support Channel and into the platform beneath (2" deep). The anchoring hardware used depends on your platform. If you have a concrete platform, we recommend using 1/4" x 2" Cement Screws, e.g., Tapcon Anchors. If you have a wood-framed platform, we recommend using 1/4" x 1" Lag Bolts. **Do not exceed a 3/8" diameter bolt.** Use a hammer drill to insert the cement screws or a regular drill to insert the Lag Bolts. Refer to your local hardware store for this hardware.

Insert Anchoring Hardware through the Floor Brackets attached to the bottom of each Wall Support and the Hinges.



CLEANING & CARE

Congratulations on your Lifetime® product purchase. By following the instructions below, your new Lifetime product should provide you with years of service and enjoyment.

Cleaning and Care

The polyethylene panels are stain- and solvent-resistant. Most stains can be removed, using a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended. Repair scratches or rust spots on the metal by sanding the affected area lightly; using a rust preventative spray primer; and finally, spraying with a high-gloss spray enamel paint. Avoid placing a direct heat source on or near surfaces unless using a heat barrier.

LIFETIME OUTDOOR SHED EQUIPMENT

10-YEAR LIMITED FACTORY WARRANTY

THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.

1. Lifetime outdoor sheds are warranted to the original purchaser to be free from defects in material or workmanship for a period of ten years from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.
2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory or distribution center are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the shed or its components are not covered under this warranty.
3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the truss will void this warranty.
4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.
6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to extent permitted by Federal and state law. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

PLEASE INCLUDE YOUR DATED SALES RECEIPT AND PHOTOGRAPHS OF DAMAGED PARTS.

REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010
or call 1-800-225-3865 M-F 7 a.m. to 5 p.m. MST.

REGISTER YOUR PRODUCT FOR QUICKER CUSTOMER SERVICE.

Visit www.lifetime.com or call 1-800-225-3865 to register your product today.

FOR INTERNATIONAL WARRANTY CLAIMS:

All warranty claims must be accompanied by a sales receipt. Report all warranty claims in writing to your regional sales support representative. Please include your dated sales receipt and photographs of damaged parts.

To identify the representative for your region — Please visit: www.lifetime.com/international



www.lifetime.com

ENHANCE YOUR LIFETIME® PURCHASE BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS

To purchase accessories or other Lifetime Products, visit us at:

www.lifetime.com

Or call: 1-800-424-3865

